



PT 235 CASH REGISTER USER MANUAL



TVS Electronics Limited

Phone: +91 81635 00400

WhatsApp: +91 74488 04201

www.tvs-e.in

Email: support@tvs-e.in

PRECAUTIONS

Follow these precautions to prevent damage and to protect against potential hazards such as electrical shock.

1. Remove protective devices before installation. Preserve unused accessories, packing materials for future use.
2. While installing this ECR, please plug the register into a grounded outlet. And keep the wires and electrical outlet in the dry place.
3. For a complete electrical disconnection, switch off and remove plug from mains. Be very careful for the manual cutter mounted on the printer cover when removing and replacing the cover, so as not to hurt you.
4. Install the cash register in a location not subject to direct sunlight, unusual temperature changes, high humidity, or splashing water.
5. Never alter or add to the mechanical or electrical design of the ECR. Unauthorized alterations might create a safety hazard. Also, any design changes or additions will void the manufacturer's warranty.
6. Never operate the cash register with wet hands. Water can cause internal component failure.
7. Clean the cash register with a dry, soft cloth. Never use volatile liquid, such as benzene or thinner. Chemicals can discolor or damage the cabinet.
8. The cash register has two types of turning off. One is hard turning off using power switch located at rear side. With this type, the standby power supply of main board supplies only for RAM, which stores the sales data. This can prevent stored data from losing. The other is soft turning off (i.e. press key [Set Cashier] to switch to off mode). There is nearly no power consumption. We suggest that you'd better select soft turning off (press key [⏻] to wake it up).
9. This cash register is an energy-saving machine. If AC is lost, after 30 minutes idles, ECR enters sleeping mode. The switch on back panel is used for long-term storage or special maintenance. In daily usage, operator should use soft switch on keyboard instead of turning on/off this switch. In case the switch in back panel need to be used, make sure before it is turned on again, it should be turned off for at least 4 minutes.
10. If there are register malfunctions, call your local dealer for service – do not repair the ECR yourself.
11. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.
12. This cash register has embedded battery. You can use it without other power supply. But you had better operate with charging if possible. It does no damage to the battery because of the embedded circuit protection.
13. This model of cash register has two battery voltage warning classes. The first warning class occurs when battery voltage is below 6.0V, and 'low B' which means low battery voltage will be displayed. The cash register beeps every 5 seconds when it is idle in the first warning class. The second warning class occurs when the battery voltage is below 5.8V, and 'low A' displayed. The cash register is out of work and immediate charge needed. Otherwise, using life of battery will be shortened and the stored data in the memory will lose most probably after a long time. The battery will discharge very slowly when not in use. Charge the battery twice a year when you do not use it and do charge for 6 hours each time.
14. All pictures in this user manual are for reference only. Please subject to the available products.

CONTENTS

1	BASIC FEATURES	1
1.1	General Descriptions	1
1.2	Technical Specifications	1
1.3	Dimension	1
1.4	Power Switch and Interface	2
2	ACCESSORIES	2
3	PAPER REPLACEMENT	3
4	BATTERY REPLACEMENT	4
5	KEYBOARD	5
5.1	Keyboard Layout	5
5.2	Function Key Description	5
6	OPERATION MODES SELECTION	8
7	LOGIN AND LOGOUT SYSTEM	9
7.1	Manager Login	9
7.2	Clerk Login and Logout	9
7.3	Clerk Manage	10
7.3.1	Steps of Adding a Clerk	10
7.3.2	Delete Clerk	11
7.3.3	Manager Set	11
7.3.4	Change PSW	12
8	HOW TO INPUT CHARACTER	12
9	SETTING IN SET MODE	13
9.1	Basic Set	13
9.1.1	Group Setting	13
9.1.2	Department Set	13
9.1.3	PLU Set	14
9.1.4	Set Price Name	15
9.1.5	Set Menu Level	15
9.1.6	Delete PLU	16
9.1.7	Clear All PLU Data	16
9.1.8	PLU Stock	16
9.1.9	Hotkey Setting	17
9.1.10	COMBO	17
9.1.11	Print Detail COMBO Sales?	17
9.1.12	Table Name Setting	17
9.2	Clerk Operation	18
9.3	Discount Set	20
9.3.1	Surcharge Rate	20
9.3.2	Discount Rate	20

9.3.3	SRV Charge.....	20
9.3.4	PLU Manual Discount?	20
9.3.5	Subtotal Discount?.....	20
9.3.6	Sale after Subt Discount?.....	20
9.3.7	Even PLU Discount	20
9.3.8	Max Change Price	21
9.4	Payment.....	21
9.4.1	Payment.....	21
9.4.2	Cash Out When Card Payment?.....	21
9.4.3	Only Allow Cash Payment in Returning?.....	22
9.4.4	Use Voucher/Limited Payment	22
9.4.5	Normal Sale Allow Cash Payment?.....	22
9.5	Security Set.....	22
9.5.1	Manager and Password Set	22
9.5.2	All Void Need PSW?.....	22
9.5.3	E/C Need PSW?	22
9.5.4	PLU Manual Discount Need PSW?.....	22
9.5.5	Subtotal Manual Discount Need PSW?	23
9.5.6	Quick Set Need PSW?	23
9.5.7	Input Password When Open Drawer?.....	23
9.5.8	Return Need PSW?.....	23
9.5.9	Allow Clerk Open Drawer?	23
9.5.10	Void Need PSW?.....	24
9.6	Receipt Set.....	24
9.6.1	Print Head Logo?.....	24
9.6.2	Print Tail Logo?.....	24
9.6.3	Set Head Message.....	24
9.6.4	Set Tail Message.....	24
9.6.5	Receipt Head Description	24
9.6.6	Kitchen Receipt Head Description	25
9.6.7	Print Head and Tail Message?.....	25
9.6.8	Enlarge Head and Tail Message?	25
9.6.9	Set Receipt Format	25
9.6.10	Print Bill No. on Receipt?.....	25
9.6.11	Print Receipt Number on Receipt?.....	26
9.6.12	Print Date on Receipt?	26
9.6.13	Print Time on Receipt?	26
9.6.14	Print Dinner's No.?.....	26
9.6.15	Print "Takeaway" Logo In The Receipt?.....	26
9.6.16	Print MC and IP?.....	26
9.6.17	Reprint Receipt by [CASH] Key?	26
9.6.18	Set Copy Receipt Times.....	27
9.6.19	Copy Receipt Even if the QTY is 0?	27
9.6.20	Only Reprint Header and Totalizer?.....	27
9.6.21	Print Login/Logout Message?.....	27
9.6.22	Void PLU Print Strikethrough?.....	27
9.6.23	Print hold receipt	27

9.6.24	Print Sale Receipt?.....	27
9.6.25	Print Non-Sale Receipt?.....	28
9.6.26	Print Report?	28
9.6.27	Print Bill?	28
9.6.28	Print Barcode?.....	28
9.6.29	Print Invoice No. on Receipt?	28
9.6.30	Print MC on Invoice?.....	28
9.6.31	Print Receipt No. on Invoice?	29
9.6.32	Set Invoice.....	29
9.6.33	Print Date on Invoice?	29
9.6.34	Print Define Store Machine No.(SMS)?	29
9.6.35	Print Totals QTY on Receipt?	29
9.6.36	Stored Receipts All Print?	29
9.6.37	Print the All Void Item in the Receipt?.....	29
9.6.38	Print Total Barcode?	30
9.6.39	Print Bill Item No.?	30
9.6.40	Font Set.....	30
9.6.40.1	Lengthen Multiple for Printing Font	30
9.6.40.2	Set Elongate Times of Time Printing in Receipt	30
9.6.40.3	Enlarge Payment Message?	30
9.7	Member Set.....	30
9.7.1	Member Card Format	30
9.7.2	Member Card Check?	31
9.7.3	Manual Input Member Card No.?	31
9.8	Remark set.....	31
9.8.1	Set PLU Remark name	31
9.8.2	Print PLU Remark?	31
9.9	Option of Clear Report.....	31
9.10	Receipt Inquire.....	32
9.10.1	Inquire Receipt by Serial No.....	32
9.10.2	Inquire Receipt by Receipt No.....	32
9.10.3	Inquire Daily Report by Z1	32
9.10.4	Print PLU List	33
9.11	Barcode Set.....	33
9.11.1	13 Code Type	33
9.11.2	Need to Verify EAN-13 Checksum?	33
9.11.3	Set Bar Code Type.....	33
9.11.4	13 Code as Goods Number?.....	33
9.12	Other.....	33
9.12.1	Set Rounding Table	33
9.12.2	Set Voucher Circulation Rate.....	34
9.12.3	AC Loss Alarm?	34
9.12.4	LCD Contrast	34
9.12.5	LCD Refurbish	34
9.12.6	Key Speed	34
9.12.7	Petrol Station Function	35
9.12.8	Set message	35

9.12.9	Power On Await Set.....	35
9.12.10	Idle Time Set	35
9.12.11	Key Sound.....	35
9.12.12	Show Version Information.....	35
10	FUNCTIONS IN SYSTEM SET MODE.....	36
10.1	Change to Training Mode/Change to User Mode Setting.....	36
10.2	Change to Tax Mode.....	37
10.3	Machine No. Program.....	37
10.4	Set Salesman/ Waiter	37
10.5	Option of Data Upload	38
10.6	Clear Sales Data.....	38
10.6.1	Erase ECR Data.....	38
10.6.2	Set the Sales Data Which Will Be Cleared	38
10.6.3	Clear Sales Data	39
10.7	Set Local Currency Symbol.....	39
10.8	Set Receipt Type	39
10.9	Date and Time Set.....	39
10.9.1	Set Date.....	39
10.9.2	Time Set	39
10.9.3	Set Daily Time Error.....	39
10.10	Set Alarm Point for Time Difference	40
10.11	Network Set	40
10.11.1	Switch Net Work Type	40
10.11.2	Set ECR IP	40
10.11.3	Set ADSL User Name and Password.....	41
10.11.4	Set Host IP	41
10.12	Organize Data	41
10.13	External Device Set.....	42
10.13.1	RS232 Device Set.....	42
10.13.2	Set Scale Type	42
10.13.3	SET KITCHEN PRINTER	42
10.13.4	DONGLE SET	43
10.13.5	GUEST PAGING SYSTEM SETTING	43
10.14	Fiscal Set	44
10.14.1	Tax Rate	44
10.14.2	Tax Head Line and Tax Tail Line	44
10.14.3	TIN No.	44
10.14.4	Price Including Tax?.....	45
10.14.5	Print Report in Spite of Zero Tax?	45
10.14.6	Printing Option	45
10.14.7	Print Tax on Receipt?	45
11	SALES OPERATIONS	46
11.1	Display System Message.....	46
11.2	Receipt Format Description.....	46
11.3	Department Sales	48

11.4	Fixed Amount Sale	48
11.5	PLU Sales	49
11.6	Discount Operation	50
11.7	[CE] Key Operation	51
11.8	[A.VOID] Key Operation	51
11.9	[VOID] Key Operation	52
11.10	Commodity Return	52
11.11	Receive on Account Operation	53
11.12	Paid Out Operation	53
11.13	Cash Transaction	54
11.14	Card Transaction	54
11.15	Payments Selecting	54
11.16	Member Card Transaction	55
11.17	[Total Qty] key operation	55
11.18	Salesman Operation	55
11.19	Hold/ Recall/ Pay	56
11.20	Takeaway Operation	56
11.21	Open a Table	57
11.22	Merge Table	58
11.23	Split Bill	59
11.24	[Customer] key operation	59
11.25	Hotkey Sale	60
11.26	Hospitality	60
11.26.1	Takeaway	60
11.26.2	The Number Of Dining	60
11.26.3	Waiter	60
11.26.4	Combo	61
11.26.5	Spilt Bill	61
11.26.6	Print Bill	61
11.26.7	Open Table	61
11.26.8	Table Merge Out	61
11.26.9	Cancel Table	61
11.27	Calculator Operation	61
11.28	ERP Operation	62
11.29	Attendance	62
12	Other Function	62
12.1	TOTAL	63
12.2	X Nopay Bill	63
12.3	COM. FUNC	63
12.4	Hospitality Functions	63
12.5	Department Set	63
12.6	PLU Set	63
12.7	Hotkey Set	63
12.8	PO	63
12.9	RA	63
12.10	Set Head Message	63

12.11	Set Tail Message	63
12.12	Tax Head/Tail Line	63
12.13	Receipt Head Description.....	64
12.14	Kitchen Receipt Head Description.....	64
12.15	Date and Time Set.....	64
12.16	Donot Print Sale REC	64
12.17	TEMP TRAIN MODE	64
12.18	Clear Sales Data.....	64
12.19	Lock Keyboard	64
12.20	Set Menu Level.....	64
12.21	PRICE INQUIRE.....	64
12.22	Redefine No.	65
12.23	Redefine Z1 No.....	65
12.24	COM TO U Disk R/W Data	66
12.25	SD/U R/W Data	67
12.26	Mem. Card.....	67
12.27	Stock Ctrl.....	68
12.28	Record Work Time.....	68
12.29	Test Net (Ethernet model)	68
12.30	Zeroing Operation	68
12.31	Tare	68
12.32	Send Sale to Egame Pos	68
13	X/Z REPORT MODE	69
13.1	Introduction	69
13.2	Report Table	69
13.3	Daily Report	70
13.4	Tax Term Report.....	71
13.5	PLU Report.....	71
13.6	Department Report.....	72
13.7	Group report	72
13.8	Time Report.....	73
13.9	Stock Report	73
13.9.1	STOCK WARNING REPORT	73
13.9.2	PLU STOCK WARNING REPORT	74
13.9.3	X STOCK REPORT	74
13.10	X Salesman/Waiter Report	75
13.11	Salesman/Waiter Commission Report	75
13.12	Table Report	76
13.13	Nopay Bill	76
13.14	Print Set Table Name	76
13.15	X Cancel/Void Report.....	77
13.16	X Bill NO. Report	77
13.17	Bill Wise Summary Report.....	78
13.18	RTN Report	79
13.19	Cash In Drawer	79
13.20	Clerk Daily Report	79

13.21	PRN Term Report	80
13.22	Z Term Report	83
13.23	Monthly Report.....	84
13.24	Attendance report.....	85
14	ERROR INFORMATION	86
15	APPENDIX.....	91

STATEMENT

For more information about software and driver, please download from

<https://www.tvs-e.in/e-cash-registers/pt-235-billing-machine/>

1 BASIC FEATURES

1.1 General Descriptions


PLU	5000
Department	99
Clerk	255
Printer	Thermal Printer
Paper Width	57mm
Display	
Customer display	14 Characters (6+8) LCD
Operator display	16 characters*4 lines (65*132 LCD)

1.2 Technical Specifications


- Battery: 7.4V 3000mAh
- DC output: 13.8V === 2.5A
- Weight: 675g
- Keyboard: 30 stroke keys
- Printing speed: 150mm/s

1.3 Dimension

Unit: mm



1.4 Power Switch and Interface



2 ACCESSORIES


When you open the carton, make sure that all accessories shown in the following are contained.



User manual




Charger



4P9D Cable

Note:



- ※ Users could apply USB/4P9D cable to connect ECR with PC. If there is a need to update the program of ECR, please contact with your dealer. The program must be downloaded by 4P9D cable.
- ※ The definition of 4P9D cable is:



Pin No.	Signal Name	Direction	Function
2	GND	-----	Frame Ground
3	RXD	Input	Receive Data
4	TXD	Output	Transmit Data

3 PAPER REPLACEMENT

1. Unclose the paper compartment cover as the arrow shows. Remove any paper residue, foreign matter and dust from the roll housing.
2. Place the paper roll in its housings and make sure that a few centimeters of paper come out from the printer front.
3. Close the cover of the paper compartment after you have caused the end of the ticket roll come out from the slot in the cover.



Notes:

1. It is essential that you use paper rolls having a colored band in the last length of paper to indicate that the paper is about to end.
2. Do not perform back feed with die cut label paper.

4 BATTERY REPLACEMENT

We use sealed lead acid battery for our ECR. Generally, new battery can be used for several years. If battery's working time is shortened apparently after charging up, please replace a new one.

CAUTION

- Risk of explosion if battery is replaced by an incorrect type
- Dispose of used batteries according to the instructions

Attentions:

1. Turn off the ECR, and disconnect the power.
2. Though the data can be stored for a long time after battery is removed, you had better replace a new one as soon as possible to prevent stored data from losing.
3. When battery is not in use for a long time, it will self-discharge gradually. Charge the battery twice a year at least when it is not in use and each time for about 6 hours.




















5 KEYBOARD












5.1 Keyboard Layout



5.2 Function Key Description


	[Function] [SHIFT]	<ol style="list-style-type: none"> 1. Tapping and holding on the key will call ‘Other Function’. 2. Shift different functions of the same key.
	[DEPT] [Calculator]	<ol style="list-style-type: none"> 1. Combine with numerical key to sell department directly. 2. Calculator key.
	[Fix Amount]	Fixed amount to sell weight cargo.
	[Hospitality]	A shortcut key for the hospitality functions.
	[Take Out]	Combine with [SHIFT] key for takeaway.
	[TABLE]	Open a table.
	[T+T]	Combine with [SHIFT] key to merge two or more tables into one.
	[CL] [ESC] [Power]	<ol style="list-style-type: none"> 1. Clear error information and cancel wrong operation 2. Exit wrong status 3. Power button to turn on/off the ECR.
	[Comm.Test]	Combine with [SHIFT] key to communicate with PC.
	[-%]	Percent discount key.
	[+%]	Percent surcharge key (Combine with [SHIFT] key).

	[CE] [←]	<ol style="list-style-type: none"> 1. Void the last transaction before settling account. 2. Delete characters one by one.
	[A.VOID]	Cancel all transactions in a receipt.
	[RETURN]	Return commodity.
	[VOID]	Void the certain item sold previously.
	[Price]	Combine with numerical key to input temporary/changed price.
	[Set Cashier]	Enter into the menu.
	[Price Inquiry]	Combine with [SHIFT] key to inquire PLU price.
	[Total Qty] [↓] [-]	<ol style="list-style-type: none"> 1. Sell weight cargo at fixed amount and weight. 2. Switch menu (downward). 3. Minus sign for calculator
	[Member]	Combine with [SHIFT] key to input member No. to sell at member price.
	[Qty] [⌚] [X]	<ol style="list-style-type: none"> 1. Sell department or PLU by quantity. 2. Time display 3. Multiple sign for calculator.
	[REPORT]	A shortcut key for report printing.
	[SBTL] [NS] [÷]	<ol style="list-style-type: none"> 1. Display the sale subtotal. 2. Open drawer when ECR is not in transaction. 3. Division sign.
	[CARD]	Settle accounts by credit card.
	[CASH] [ENTER] [=]	<ol style="list-style-type: none"> 1. Calculates the sale total, finalizes the sale, and opens the cash drawer. 2. Enter key. 3. Equal symbol.
	[Payment]	Combine with key [SHIFT] to select different payment methods during transaction.
	[HOLD] [RECALL]	<ol style="list-style-type: none"> 1. Store a bill before finalizing a sale transaction. 2. Recall the stored bill.
	[Discount]	Combine with key [SHIFT] to discount on amount during transaction.
	[PLU]	Sell PLU by PLU number.
	[PLU Edit]	Edit PLU information.
	[.]	To set decimal point.
	[Customer]	Combine with [SHIFT] key to input customer information.

	[0]...[9]	<ol style="list-style-type: none"> Numerical key Symbol key Letter key
	[0] 	<ol style="list-style-type: none"> Numerical key. Symbol key Tap and hold on the key to lock keyboard
	[Promoter]	Combine with key [SHIFT] to input promoter information.
	[3] [DEF] [Cloud OP]	<ol style="list-style-type: none"> Numerical key. Letter key Tap and hold on the key to call 'Cloud OP' function.
	[5] [JKL] [ERP]	<ol style="list-style-type: none"> Numerical key. Letter key Tap and hold on the key to call 'ERP' function
	[6] [MNO] [Attendance]	<ol style="list-style-type: none"> Numerical key. Letter key Tap and hold on the key to call 'Attendance' function
	[8] [TUV] [RA]	<ol style="list-style-type: none"> Numerical key. Letter key Tap and hold on the key to put money into drawer during non-transaction.
	[9] [WXYZ] [PO]	<ol style="list-style-type: none"> Numerical key. Letter key Tap and hold on the key to draw money out of drawer during non-transaction.
	[V1]	Hotkey 1
	[PLU Remark]	Combine with key [SHIFT] to add PLU remark during transition.
	[V2]	Hotkey 2
		Combine with key [SHIFT] to call hotkey 4.
	[V3] [↑] [+]	<ol style="list-style-type: none"> Hotkey 3. Used to switch the function item. (Upward). Plus key for calculator.
		Combine with key [SHIFT] to call hotkey 5.

6 OPERATION MODES SELECTION

Please read the corresponding chapter for the functions of each mode.



Clerk must login before any sales operation. Refer to 7.2 chapter “Clerk Login and Logout” for a description of clerk operations.

Almost all reports can be printed in X and Z mode. The difference between them is:

In X mode, total sales sum is not set to zero after printing report, next sales sum will be accumulated.

In Z mode, total sales sum is set to zero after printing report, next sales sum will be calculated from the beginning of zero.

“FACTORY TEST FUNCTION” is destined for service engineers who carry out the assistance and maintenance of the ECR.

“SHOW SYSTEM MSG” will display some information of the ECR. Such as version, time, voltage, IP and so on.

“SLEEP” is Sleep Mode. Select this item and then press [CASH], or press [CL/ESC] for about 3 seconds, it can enter into Sleep Mode. If ECR is in Sleep Mode for 15 minutes, it will soft off automatically. You can press [CL/ESC] to wake it up from Sleep Mode or turn on it.

Attention: If sales transaction has been done, only after printing Z daily report can you see all items in SET mode. Please refer to chapter 13.3 for daily report printing.

7 LOGIN AND LOGOUT SYSTEM

7.1 Manager Login

Manager Password:

This password is used for manager to enter SET mode, X REPORT, Z REPORT and SYSTEM SET mode. You can set 32 managers, and the password is not more than 8 digits.

- 1) The No.1 manager can set other managers' passwords and rights purviews.
- 2) No. 2~32 managers only can set their own passwords.
- 3) There is a default manager, No.1 with password 0. When you use the ECR for the first time, you need to enter SET mode as No.1 manager, to change the password and set other managers' purviews.
- 4) Login: + [CASH] + + [CASH].

For instance: No.1 manager with password 0 login SET mode, press [CL], and use key [↑] or [↓] to choose SET, press [CASH], then press key:

[1] + [CASH] + [0] + [CASH]

7.2 Clerk Login and Logout

Attention:

The cash register will beep when error occurs.

Any sales operation will cause error until clerk login.


The cash register does not work without a clerk login. Each receipt has a clerk mark to identify the clerk is on duty. To guarantee the reality of sales report, each clerk has an exclusive login password.

Method of login system:

Method 1:

1. Press [CL] key several times until it returns to the initial status, and then press [Set Cashier].

LCD displays:



2. Use [↑] or [↓] key to select "CLERK LOGIN" item, press [CASH] key to confirm.
3. System prompts: "CLERK", input the clerk number, press [CASH] key to confirm.
4. System prompts: "CLERK PSW", input password, press [CASH] key to confirm. If the clerk has no password, you can press [CASH] key directly.

Method 2:

1. Press [CL] key several times until it returns to the initial status;
2. Input the clerk number and then press [Set Cashier]. If the clerk has no password, the system won't prompt to input the password. If not, the system prompts to input clerk's password. Input the clerk's password, and then press [CASH] to confirm.

Note:

1. **There are 8 default clerks from 1 to 8 with the login password 0.**
2. **Allow 8 clerks at most logging in ECR each day, otherwise the system will show the error "Error 46 CLERK FULL".**
3. **After entering into "CLERK MANAGE", clerk number, clerk password and purview can be set; there are totally 255 clerks can be set. (Refer to chapter7.3)**

Methods of logging out the system:

Press [CL] key until the LCD display:

CLERK: 1
0

Press [Set Cashier] key to display the main menu, select "CLERK LOGOUT" item, then press [CASH] key to confirm.

Note: The clerk can log in the system even if another clerk hasn't logged out.

7.3 Clerk Manage

Note:

1. **Only managers authorized with "CLERK MANAGE" purview can enter into this mode. And no clerk login while entering this mode.**
2. **No.1 clerk is the super manager with all purviews and cannot be changed. Only the super manager can set other managers' purviews while other managers can only set their own purviews.** In this function, the clerk number, password and purview can be set. You can set 255 clerks at most. After entering this item, the LCD displays:

ADD
DEL
MANAGER SET
CHANGE PSW

7.3.1 Steps of Adding a Clerk

1. Use key [↑] or [↓] to select 'ADD', press [CASH] key to enter.
2. Input the clerk number, press [CASH] key to confirm. You can set an arbitrary number not more than 8 digits for each clerk, but the total amount of clerk is not more than 255.
3. After the system prompts: <CLERK NAME>, input the clerk's name, press [CASH] key to confirm.
4. After the system prompts: <CLERK PSW>, input the clerk password (8 digits at most), press [CASH] key to confirm.

5. The system prompts: <CONFIRM CLERK PSW>, input the clerk password again to confirm.
6. You can set some purview for the first clerk to the 32nd one. The LCD will display the following items:

CHECK ALL
 + X REPORT
 RTN MODE
 SET
 Z REPORT
 + CLERK MANAGE
 + SYSTEM SET
 ADD TO STOCK
 CHECK STOCK
 CHANGE PSW
 OPEN DRAWER

7. Use the key [↑] or [↓] to select the purview, and press [CASH] key to switch on or off. The symbol ‘+’ in the front of the item shows this purview is open for this clerk.
8. Press [CL] key to exit after setting.

Note:

If you set the purview ‘SET’ for the clerk, this clerk can enter SET mode without manager password. Clerks from No.1 to No.32 are namely the 32 managers.


7.3.2 Delete Clerk

1. Use key [↑] or [↓] to select ‘DEL’, press [CASH] key to enter.
2. Input the clerk’s number which you want to delete, press [CASH] key.
3. Use key [↑] or [↓] to choose YES or NO, press [CASH] key to confirm.

7.3.3 Manager Set

The ECR can set 32 managers from No.1 to No. 32 (namely clerks from No.1 to No. 32). And the No. 1 is the super manager, only who can change other managers’ purview. So, you must be careful to do this setting.

1. Use [↑] or [↓] to select “MANAGER SET”, press [CASH].
2. System prompts: <Input Manager NO.>, input a manager number from 1 to 32 and press [CASH] to confirm.



3. Press key [CASH] to change the manager's right. "+" means open the corresponding right. If you choose 'CHECK ALL' and press [CASH], all rights are chosen. After finishing the setting, press [CL] to exit directly.

Note: If a manager doesn't have the "CLERK STOCK" right, then when this manager login, there will be only the "SEARCH PLU STOCK" in the "PLU Stock" setting, and there won't be the "STOCK" item in the PLU Setting.

7.3.4 Change PSW

1. Use key [↑] or [↓] to select 'CHANGE PSW', press [CASH] key to enter.
2. Input the clerk's number whose password you want to change, press [CASH] key.
3. The system prompts: <OLD PSW>, input old password, press [CASH] key.
4. After the system prompts: <CLERK NEW PSW>, input new password, and press [CASH] key.
5. The system prompts: <CONFIRM CLERK PSW>, input new password again, press [CASH] key to confirm.

8 HOW TO INPUT CHARACTER

Character input is required while inputting PLU name, department name, foreign currency name, etc. The method of inputting character is described as follows:

Each numeric key represents several different letters, number and interpunctons. You can find these letters, number and interpuncton on each numerical key button. For example, the key [2] can be used to input "A", "B", "C" and "2".

To input the letter you want, you should switch the input method by pressing [SBTL] first, and then successively press the corresponding numerical key some times until the letter is shown on the LCD. Function keys as follows:

[SBTL]	Shift between letters and digits.
[←]	Delete characters one by one
[SHIFT]	Shift between upper/lower cases.

9 SETTING IN SET MODE

Attention:

1. The machine beeps when an error occurs, and the error message 'ERR X' is displayed. Please refer to chapter 14 for details.
2. Print the Z daily report before entering SET mode.

Following items can be set in SET mode:

- ✧ BASIC SET
- ✧ CLERK OPERATION
- ✧ DISCOUNT SET
- ✧ PAYMENT
- ✧ SECURITY SET
- ✧ RECEIPT SET
- ✧ MEMBER SET
- ✧ REMARK SET
- ✧ OPTION OF CLEAR REPORT
- ✧ RECEIPT INQUIRE
- ✧ BARCODE SET
- ✧ OTHER

Press key [Set Cashier] to shift to SET mode, and then press [CASH] key. Input manager number and password, and then press key [CASH] to enter. Clerks authorized with 'SET' operation do not need to input manager number and password.

9.1 Basic Set

9.1.1 Group Setting

1. Use key [↑] or [↓] to select 'GROUP SET' item, and press key [CASH] to enter this function.
2. After system prompts :< GROUP NUM>, input the group number ranging from 1 to 99, and press key [CASH] to confirm.
3. After system prompts :< GROUP NAME>, set group name (please refer to chapter 8 for character inputting method), and press key [CASH] to confirm.

9.1.2 Department Set

Department information can be downloaded from PC software, and it can also be set through keyboard directly.

1. Use key [↑] or [↓] to select 'DEPARTMENT SET' item, and press key [CASH] to enter this function.
2. After system prompts: <DEP NUM>, input the department number ranging from 1 to 99, and then press [CASH] to confirm.
3. After system prompts: <DEP NAME>, input the department's name, and press [CASH] to confirm. (Please refer to chapter 8 for 'HOW TO INPUT CHARACTER'.)
4. After system prompts: <DEP PRICE>, input the department's price (0~99999.99) and press key [CASH] to confirm.
5. After system prompts: <TAX (0~8)>, input the corresponding number to set the tax index (0 is no tax

- rate), press [CASH] key to confirm. **(This item will be shown only when ECR is in tax mode.)**
6. After system prompts: <KITCHEN PRINTER IDX (0~16) (O: No [.] separator)>, input the connected kitchen printer's index, and press [CASH] key to confirm.
 7. After system prompts: <DEP - % DISCOUNT OFF>, set the discount rate, and then press [CASH] key to confirm.
 8. After system prompts: <DEP MEM - % DISCOUNT OFF >, set the member discount rate, press key [CASH] to confirm.
 9. After system prompts :< COMMISSION (%)>, set commission rate, and press key [CASH] to confirm.
 10. After system prompts: <GROUP NUM>, input group number to set group linked, and press key [CASH].
 11. LCD displays: <IS ALLOW SUBTOTAL DISCOUNT? (0. ALLOW 1. NO ALLOW)>, it means whether to allow discount after subtotal, input 0 for allow or 1 for no allow and press [CASH].
 12. The system will print a ticket where displays the information of the department set.

Note:

1. Press key [CASH] to skip the items if unnecessary.
2. Quick Setting Method: press key [0][0][DEPT] to enter quick setting.

9.1.3 PLU Set

PLU information can be downloaded from computer and it can also be set through keyboard directly. The steps are similar to department setting.

1. Use key [↑] or [↓] to select 'SET/BASIC SET/PLU SET' item, and press key [CASH] to enter.
2. System prompts: <BARCODE>, input the PLU barcode which you want to modify or input the new PLU barcode, and then press [CASH] key to confirm.
3. System prompts: <NAME>, input PLU name and press [CASH] key to confirm.
4. System prompts: <Normal>, input PLU normal price (the max value is 99999.99), and press [CASH] key to confirm.
5. System prompts: <Lunch>, input PLU price for lunch (the max value is 99999.99), and press [CASH] key to confirm.
6. System prompts: <Dinner>, input PLU price for dinner (the max value is 99999.99), and press [CASH] key to confirm.
7. System prompts: <Takeaway>, input PLU price for takeaway (the max value is 99999.99), and press [CASH] key to confirm.
8. System prompts: <MEMBER PRICE>, input PLU price which is for member card payment, and press key [CASH] to confirm.
9. System prompts: <PURCHASE PRICE>, input PLU purchase price and press key [CASH] to confirm.
10. System prompts: <TAX IDX (0~8)>, input the corresponding number to set the tax index (0 is no tax rate), press [CASH] key to confirm. **(This item will be shown only when ECR is in tax mode.)**
11. System prompts: <PLU TYPE (0: NORMAL 1: COMBINE 2: WEIGHT CARGO 3: OIL 4: PCS TYPE)>, input the corresponding number to choose a type, press [CASH] key to confirm.
12. System prompts: <1/2 PRICE>, input 1/2 price, and press [CASH] key to confirm. **(Note: this item shows when PLU type is set to NORMAL)**
13. System prompts: <1/4 PRICE>, input 1/4 price, and press [CASH] key to confirm. **(Note: this item shows when PLU type is set to NORMAL)**
14. System prompts: <ALLOW MANUAL CHANGE PRICE (0: NO 1: YES)>, input 0 or 1 to choose whether to allow changing PLU price manually, and press [CASH] key to confirm. (The default setting is YES.)

0: not allow to change PLU price manually;

1: allow to change PLU price manually

15. System prompts: <ALLOW RTN (0: NO 1: YES)> input 0 or 1 to choose whether to allow PLU return, and press [CASH] to confirm.
 0: not allow PLU return;
 1: allow PLU return
16. System prompts: <DEP NUM>, input department No. PLU belongs to, and then press [CASH] to confirm.
17. System prompts: <STOCK>, input the PLU stock quantity, press [CASH] key to confirm.
18. System prompts: < PLU STOCK WARN >, input the PLU stock warning threshold, press [CASH] key to confirm.
19. System prompts: <UNIT>, input the PLU unit, press [CASH] key to confirm.
 The system will print a ticket where displays the information of PLU set.

Note:


1. Press [CASH] to skip the items if unnecessary.
2. **Quick Setting Method: press key [0][0][PLU] to enter quick setting. If you set the item ‘SECURITY SET/QUICK SET NEED PSW?’ to ‘NO’ under SET mode, no need to input the manager number and password here.**

9.1.4 Set Price Name

1. Use key [↑] and [↓] to select ‘SET PRICE NAME’ item. Press [CASH] to enter.
2. System prompts: <INPUT PRICE NAME IDX (1~4)>, input the price index number, then edit the price name and press [CASH] to save.
3. After setting, the 4 kinds of price names of each PLU will be displayed when you enter the item “SET MENU LEVEL” (Chapter 9.1.5).

9.1.5 Set Menu Level

This function is used to choose the price type of PLU.
 The LCD displays:



1. Use key [↑] and [↓] to select a price type for sale.
2. If you choose ‘CHOICE PRICE’, you need to choose one of the four prices every time when selling PLU.
3. If you choose ‘Normal’ or ‘lunch’ or ‘dinner’ or ‘takeaway’, you need not to choose the price type again when selling PLU, it will be sold at the chosen type automatically.

Note: ‘Normal’, ‘lunch’, ‘dinner’ and ‘takeaway’ are the default price name, they can be edited in the item ‘SET PRICE NAME’. (Refer to chapter 9.1.4)

9.1.6 Delete PLU

This item is used to delete PLU data.

1. Use key [↑] or [↓] to select 'DELETE PLU' item, and press key [CASH] to enter this function.
2. System prompts: <INPUT BARCODE TO DELETE>, input PLU barcode and press [CASH] key to confirm.
3. Use key [↑] or [↓] to select YES or NO to delete.

Note: if you choose 'YES', the corresponding PLU data will be erased.

9.1.7 Clear All PLU Data

This item is used to clear all PLU data in the cash register.

1. Use key [↑] or [↓] to select 'CLEAR ALL PLU DATA' item, and press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select YES or NO to clear all PLU data.

Note: if you choose 'YES', all PLU data will be cleared.

9.1.8 PLU Stock

● Search PLU Stock

This item is used to search the certain PLU stock.

1. Use key [↑] or [↓] to select 'SEARCH PLU STOCK' item, and press key [CASH] to enter.
2. System prompts: <PLU CODE>, input the PLU barcode to inquire, press [CASH] to confirm. The operator LCD will display the PLU name and stock.
3. Press key [CL] to exit.

● Add PLU Stock

This function is used for PLU stocks adding.

1. Use key [↑] or [↓] to select 'ADD PLU STOCK' item, and press key [CASH] to enter.
2. System prompts: <INPUT VENDER NO.>, input the vender No., and press key [CASH] to confirm.
3. System prompts: <INPUT DC NO.>, input the received note No., and press key [CASH] to confirm.
4. System prompts: <BARCODE>, input the PLU barcode, press [CASH] key to confirm.
5. System prompts: <PURCHASE PRICE>, input the PLU purchase price, press [CASH] key.
6. System prompts: <PLU STOCK>, input the added quantity, press [CASH] key to confirm.

● Delete PLU Stock

This function is used to register the decrease in stocks.

1. Use key [↑] or [↓] to select 'DEL PLU STOCK' item, and press key [CASH] to enter.
2. System prompts: <BARCODE>, input the PLU barcode, press [CASH] key to confirm.
3. System prompts: <PLU STOCK>, input the reduced quantity, press [CASH] key to confirm.

Note: after setting of 'ADD PLU STOCK' or 'DEL PLU STOCK', the machine will print a receipt to display the ultimate stock.

● Check Stock

This function is used to check PLU stocks.

1. Use key [↑] or [↓] to select 'CHECK STOCK' item, press key [CASH] to enter this function.
2. System prompts: <BARCODE>, input the PLU barcode, press [CASH] key to confirm.

3. System displays PLU name and its current stocks, press [CASH] to confirm if there is no disparity, or input the actual stocks and press [CASH] to confirm, then ECR will change to the amount you inputted.

9.1.9 Hotkey Setting

Users can set hotkeys for the popular commodities, and press the corresponding hotkey directly when selling the popular commodities. There are totally 5 hotkey can be set.

- a. Use key [↓] or [↑] to select the function ‘HOTKEY SET’ and press key [CASH] to enter.
 - b. After system prompts: <HOTKEY NUM>, input a hotkey number ranging from 1~5, and press key [CASH] to confirm.
 - c. After system prompts: <Input Flag (0.PLU 1.MEAL 2.DEP)>, input corresponding number to set hotkey flag, and press key [CASH] to confirm.
1. System prompts to input barcode if selecting ‘0.PLU’ here, more PLU setting details please refer to chapter 9.1.3;
 2. Input the meal number if selecting ‘1. MEAL’ here;
 3. System prompts to input department number if selecting ‘2.DEP’ here, more DEP setting details please refer to chapter 9.1.2;

9.1.10 COMBO

1. Use key [↓] or [↑] to select the function ‘COMBO’ and press key [CASH] to enter.
2. After system prompts :< SET COMBO IDX>, input combo index and press key [CASH].
3. After system prompts :< NAME>, set combo name, and press key [CASH].
4. After system prompts :< PRICE>, set combo price, and press key [CASH].
5. Do as system prompt to set the rest of items. (refer to chapter 9.1.2)
6. After system prompts :< ITME BARCODE (no input and press [CASH] to confirm)>, input combo barcode if any, otherwise press key [CASH] directly to confirm.

9.1.11 Print Detail COMBO Sales?

This item is to set whether to print detail combo sales during selling combo.

9.1.12 Table Name Setting

There are totally 128 table can be set.

1. Use key [↓] or [↑] to select the function ‘SET TABLE NAME’ and press key [CASH] to enter.
2. After system prompts: <INPUT TABLE IDX (1~128)>, input table index. (Ranging from 1 ~128), and press key [CASH] to confirm.
3. After system prompts: <INPUT TABLE NEW NUM>, input table No.(at most 8 digit), and press key [CASH] to confirm.
4. After system prompts: <INPUT TABLE NAME>, set table name and press key [CASH] to confirm.

9.2 Clerk Operation

No.	Item	Description	Default Setting
1	NO SALES OPEN DRAWER?	Whether to allow opening the drawer when there is no sales transaction?	YES
2	HOLD ORDER WITHOUT OPEN TABLE?	Whether to allow holding a receipt without opening a table? Note: if the setting is “YES”, you can hold 5 receipts at most with a hold No. ranging from 124 to 128. Input the code (124~128), and then press [Table] key to recall the order. If the setting is “NO”, it is necessary to open a table before holding, and the hold No. ranges from 1 to 123.	YES
3	LOGOUT EVEN IF THERE IS ORDER HELD?	Whether clerks are allowed to logout when there are still receipts being held?	YES
4	CLEAR REP IF THERE IS ORDER HELD?	Whether to allow printing Z reports when there are still receipts being held?	YES
5	PRINT RECEIPT AFTER CHECK OUT?	Whether to print the receipt after check-out? Note: If the setting is “YES”, the receipt will be printed only after settling accounts. If the setting is “NO”, the receipt will be printed with input info on it as long as doing sales operation, and finally the whole receipt will be printed after settling accounts.	YES
6	INPUT AMOUNT BEFORE PAYMENT?	Whether to force inputting amount before paying?	NO
7	INPUT RECEIPT NO.?	Whether to input receipt number when selling PLU? Note: If the setting is “YES”, when selling PLU, the system will prompt to input number. Here, you can define a receipt number at will. If the setting is “NO”, it is no need to input a receipt number when selling PLU.	NO
8	INPUT SALESMAN/ WAITER ID?	Whether need to input salesman or waiter ID number when selling PLU?	NO
9	NEED TO INPUT TABLE NO.?	Whether need to open a table before selling PLU?	NO
10	MANUAL CHANGE PRICE?	Whether to allow changing PLU price manually when selling PLU?	YES

11	ALLOW NEGATIVE STOCK?	Whether to allow selling PLU when the stock is negative?	YES
12	ALLOW ZERO PRICE SALE?	Whether to allow selling PLU with zero price?	YES
13	MANUAL INPUT QTY?	Whether to allow inputting quantity manually?	NO
14	PRINT QTY ON TOTAL PRICE LABEL?	Whether to print the total quantity on the receipt?	NO
15	PRN QTY & PRICE ON TOTAL PRICE LABEL?	Whether to print the total quantity and price on the receipt?	YES
16	INPUT PRICE BY HOTKEY?	Whether to input price by hotkey?	NO
17	SHOW VOUCHER BALANCE?	Whether to show the voucher balance on the voucher? Note: set 'PAYMENT/ USE VOUCHER/ LIMITE PAYMENT' to 'YES' (refer to chapter 9.4.4 for details).	NO
18	QUANTITY LIMIT?	Whether the quantity is limited on a receipt?	NO
19	CATEGORY SALES SEARCH BY PAGE?	Whether press [↑] or [↓] key to search category by page?	NO
20	CLERK LOGOUT AFTER CHECK OUT?	Whether the clerk logout automatically after settling accounts? Note: It will be invalid if the item 'LOGOUT EVEN IF THERE IS ORDER HELD?' is set "NO".	NO
21	KITCHEN PRINT RECEIPT AFTER CHECK OUT?	Whether the kitchen printer prints the receipt after settling accounts?	YES
22	KITCHEN PRINT HOLD RECEIPT?	Whether the kitchen printer prints the hold receipt?	YES
23	SALESMAN/WAITER WORK ON COMMISSION?	Whether salesman and waiter works on commission.	NO
24	SUMMARY QTY FOR THE SAME PLU SALES?	Whether to summary QTY for the same PLU sales in one receipt?	NO
25	USE GUEST PAGING SYSTEM?	Whether to use guest paging system?	NO
26	CLOSE CALCULATOR?	Whether to close the calculator function?	NO
27	PLU STOCK WARNING?	Whether warning if the PLU quantity is less than the specific value.	NO

9.3 Discount Set

9.3.1 Surcharge Rate

1. Use key [↑] or [↓] to select ‘SURCHARGE RATE’ item, press key [CASH] to enter.
2. After the system prompts: <SURCHARGE RATE (00.00~99.99)>, and input the rate value, and press [CASH] key to confirm.

Example: 20.15% surcharge

Press [2][0][.][1][5][CASH]

9.3.2 Discount Rate

1. Use key [↑] or [↓] to select ‘DISCOUNT RATE’ item, press key [CASH] to enter.
2. After the system prompts: <DISCOUNT RATE (00.00~99.99)>, and input the rate value, then press [CASH] key to confirm.

Example: 10% discount

Press [1][0][CASH]

9.3.3 SRV Charge

1. Use key [↑] or [↓] to select ‘SRV CHARGE’ item, press key [CASH] to enter.
2. After system prompts :< RATE (00.00~99.99)>, input rate value, and then press key [CASH] to confirm.

9.3.4 PLU Manual Discount?

This item is to set whether to allow PLU discount manually.

1. Use key [↑] or [↓] to select ‘PLU MANUAL DISCOUNT?’ item, press key [CASH] to enter.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.3.5 Subtotal Discount?

This item is to set whether to allow subtotal discount.

1. Use key [↑] or [↓] to select ‘SUBTOTAL DISCOUNT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.3.6 Sale after Subt Discount?

This item is to set whether to allow sale after subtotal discount.

1. Use key [↑] or [↓] to select “SALE AFTER SUBT DISCOUNT” item, press key [CASH] to enter.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

Note: Set the item ‘DISCOUNT SET/SUBTOTAL DISCOUNT’ to YES in SET mode, set the item ‘CLERK OPERATION/PRINT RECEIPT AFTER CHECK OUT?’ to NO in SET mode, then you can see this item.

9.3.7 Even PLU Discount

Note: Set the item ‘DISCOUNT SET/SUBTOTAL DISCOUNT?’ to YES in SET mode, and set the

item ‘CLERK OPERATION/PRINT RECEIPT AFTER CHECK OUT?’ to NO in SET mode, then you can see this item.

In this function, you can choose whether even subtotal discount to every PLU.

1. Use key [↑] or [↓] to select ‘EVEN PLU DISCOUNT?’ item, press key [CASH] to enter this function.
2. Input number 1 or 0 to select ‘YES’ or ‘NO’.

9.3.8 Max Change Price

This item is to set the max amount of changing price manually.

1. Use key [↑] or [↓] to select “MAX CHANGING PRICE” item, and press key [CASH] to confirm.
2. System prompts :< INPUT MAX CHANGE PRICE>, input the ceiling value and press key [CASH].

9.4 Payment

9.4.1 Payment

1. Use key [↑] or [↓] to select ‘PAYMENT’ item, press key [CASH] to enter this function.
2. System prompts: <PAYMENT IDX>, input the digit range from 1 to 20, then press [CASH] key to confirm.
3. System prompts: <PAYMENT>, input the payment name (please refer to chapter 8 for ‘HOW TO INPUT CHARACTER’), such as member card payment which will be printed on the receipt. Press [CASH] key to confirm.
4. LCD displays:

CASH
TICKET PAY
CREDIT
CHECK

Use key [↑] or [↓] to select the corresponding payment, and press key [CASH] to confirm.

5. System prompts: <ROUND (0: ROUND 1: NOT ROUND)>, input number 0 or 1, press [CASH] key to confirm.
6. System prompts: <ALLOW CHANGE (0.NO 1.CASH 2.CHANGE LITTLE)>, input corresponding number to set the method of giving changes, press [CASH] key to confirm.
 - 0: don’t give changes
 - 1: give changes in cash
 - 2: give changes by voucher or some tickets like this.

Note: If the attribute of the first payment is check, the function key [PAYMENT CHECK] will be defaulted as [CHECK] key only; if not, you can press [PAYMENT CHECK] key directly to choose a payment.

9.4.2 Cash Out When Card Payment?

This function is to choose whether to allow giving changes when using card payment.

1. Use key [↑] or [↓] to select ‘CASH OUT WHEN CARD PAYMENT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select ‘YES’ or ‘NO’, and press [CASH] to confirm.

9.4.3 Only Allow Cash Payment in Returning?

This function is to choose whether to allow cash payment only in returning.

1. Use key [↑] or [↓] to select ‘ONLY ALLOW CASH PAYMENT IN RETURNING?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select ‘YES’ or ‘NO’, and press [CASH] to confirm.

9.4.4 Use Voucher/Limited Payment

This function is to choose whether to use voucher or limited payment.

1. Use key [↑] or [↓] to select “USE VOUCHER/LIMITED PAYMENT” item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.4.5 Normal Sale Allow Cash Payment?

This function is to choose whether to allow cash payment during normal sales operation.

1. Use key [↑] or [↓] to select ‘NORMAL SALE ALLOW CASH PAYMENTS?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5 Security Set

9.5.1 Manager and Password Set

● Change Super PSW

Super password is the highest password. It can replace all the passwords used in this machine. So we suggest that you should keep the password in the super manager.

1. Use [↑] or [↓] to select ‘CHANGE SUPER PSW’, press [CASH].
2. Do as the LCD prompts.

Note: The default super password is 00000000. We suggest you change it as soon as possible.

9.5.2 All Void Need PSW?

This function is to choose whether need to input password during all void operation.

1. Use key [↑] or [↓] to select ‘ALL VOID NEED PSW?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5.3 E/C Need PSW?

This function is to choose whether need to input password during [EC] operation.

1. Use key [↑] or [↓] to select ‘E/C NEED PSW?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5.4 PLU Manual Discount Need PSW?

This function is to choose whether need to input password when PLU manual discount.

1. Use key [↑] or [↓] to select “PLU MANUAL DISCOUNT NEED PSW?” item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

Note: Set the item “DISCOUNT SET/PLU MANUAL DISCOUNT?” to “YES” in “SET” mode, then you can see this item.

9.5.5 Subtotal Manual Discount Need PSW?

This function is to choose whether need to input password when PLU manual discount.

1. Use key [↑] or [↓] to select “SUBTOTAL MANUAL DISCOUNT NEED PSW?” item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

Note: Set the item “DISCOUNT SET/SUBTOTAL DISCOUNT?” to “YES” in “SET” mode, then you can see this item.

9.5.6 Quick Set Need PSW?

This function is to choose whether need to input password when quick setting PLU, department and hotkey.

1. Use key [↑] or [↓] to select the item ‘QUICK SET NEED PSW?’, and press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5.7 Input Password When Open Drawer?

This function is to choose whether need to input password when open drawer.

1. Use key [↑] or [↓] to select the item ‘INPUT PASSWORD WHEN OPEN DRAWER?’, and press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5.8 Return Need PSW?

This function is to choose whether need to input password when returning sales.

1. Use key [↑] or [↓] to select the item ‘RETURN NEED PSW?’, and press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5.9 Allow Clerk Open Drawer?

It is used to set whether clerks are allowed to open the drawer or not.

1. Use key [↑] or [↓] to select the item ‘ALLOW CLERK OPEN DRAWER?’, and press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.5.10 Void Need PSW?

This function is to choose whether need to input password during void operation.

1. Use key [↑] or [↓] to select ‘VOID NEED PSW?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6 Receipt Set

9.6.1 Print Head Logo?

This function is to choose whether to print head logo on receipt.

1. Use key [↑] or [↓] to select ‘PRINT HEAD LOGO?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.2 Print Tail Logo?

This function is to choose whether to print tail logo on receipt.

1. Use key [↑] or [↓] to select ‘PRINT TAIL LOGO?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.3 Set Head Message

This function is mainly used to edit the header message of the receipt.

1. Use key [↑] or [↓] to select the item ‘SET HEAD MESSAGE’, and press key [CASH] to enter this function.
2. After the system hints to <HEAD MESSAGE INDEX (1~5)>, input the line number that needs modifying.
3. System prompts: <HEAD MESSAGE>, input the message, and press [CASH] key to confirm. (Please refer to chapter 8 for ‘HOW TO INPUT CHARACTER’.

9.6.4 Set Tail Message

This function is mainly used to edit the footer message of the receipt.

1. Use key [↑] or [↓] to select ‘SET TAIL MESSAGE’ item, press key [CASH] to enter this function.
2. After the system prompts: <TAIL MESSAGE INDEX (1~2)>, input the line number that needs modifying.
3. System prompts: <TAIL MESSAGE>, input the message, and press [CASH] key to confirm. (Please refer to chapter 8 for ‘HOW TO INPUT CHARACTER’.)

9.6.5 Receipt Head Description

This function is to set receipt head message.

1. Use key [↑] or [↓] to select ‘RECEIPT HEAD DESCRIPTION’ item, press key [CASH] to enter.
2. After the system prompts <DESCRIPTION>, edit the head description, press [CASH] to confirm.

9.6.6 Kitchen Receipt Head Description

This function is to set receipt head description printed by kitchen printer.

1. Use key [↑] or [↓] to select 'KITCHEN RECEIPT HEAD DESCRIPTION' item, press key [CASH] to enter.
2. After the system prompts <DESCRIPTION>, edit the head description, press [CASH] to confirm.

9.6.7 Print Head and Tail Message?

This function is to choose whether to print head and tail message on receipt.

1. Use key [↑] or [↓] to select 'PRINT HEAD AND TAIL MESSAGE?' item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select "YES" or "NO", and press [CASH] to confirm.

Note: If both the item 'PRINT HEAD LOGO?' and 'PRINT TAIL LOGO?' are set to 'NO', then whether you set this item to 'YES' or 'NO', the message will be printed.

9.6.8 Enlarge Head and Tail Message?

This function is to choose whether to enlarge head and tail message.

1. Use key [↑] or [↓] to select 'ENLARGE HEAD AND TAIL MESSAGE?' item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select "YES" or "NO", and press [CASH] to confirm.

9.6.9 Set Receipt Format

This function is to set the receipt format. There are five columns on the receipt: name, discount, price, quantity and amount. Set each column width here. The total width cannot be more than 29 characters.

1. Use key [↑] or [↓] to select 'SET RECEIPT FORMAT' item, and then press key [CASH] to enter.
2. System prompts: <Input Name Width (4)>, input the name column width not less than 4, and then press [CASH] key to confirm. The default setting is 4.
3. System prompts: <Input Discount Width (6)>, input the discount column width not less than 4, and then press [CASH] key to confirm. The default setting is 6.
4. System prompts: <Input Price Width (7)>, input the price column width not less than 4, and then press [CASH] key to confirm. The default setting is 7.
5. System prompts: <Input Qty Width (5)>, input the quantity column width not less than 4, and then press [CASH] key to confirm. The default setting is 5.
6. System prompts: <Input Amt Width (7)>, input the sum amount column width not less than 4, and then press [CASH] key to confirm. The default setting is 7.

Note: The total width of these 5 columns cannot be more than 29 characters.

9.6.10 Print Bill No. on Receipt?

This function is to choose whether to print bill number on the receipt.

1. Use key [↑] or [↓] to select 'PRINT BILL NO. ON RECEIPT?' item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select "YES" or "NO", and press [CASH] to confirm.

9.6.11 Print Receipt Number on Receipt?

This function is to choose whether to print receipt number on the receipt.

1. Use key [↑] or [↓] to select ‘PRINT RECEIPT NUMBER ON RECEIPT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.12 Print Date on Receipt?

This function is to choose whether to print date on receipt.

1. Use key [↑] or [↓] to select ‘PRINT DATE ON RECEIPT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.13 Print Time on Receipt?

This function is to choose whether to print time on receipt.

1. Use key [↑] or [↓] to select ‘PRINT TIME ON RECEIPT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.14 Print Dinner’s No.?

This function is to set whether to print dinner’s No. on receipt.

1. Use key [↑] or [↓] to select ‘PRINT DINNER’S NO.?’ item, press key [CASH].
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.15 Print “Takeaway” Logo In The Receipt?

This function is to set whether to print “TAKEAWAY” logo on receipt.

1. Use key [↑] or [↓] to select ‘PRINT “TAKEAWAY” LOGO IN THE RECEIPT?’ item, press key [CASH].
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.16 Print MC and IP?

This function is to choose whether to print MC and IP on receipt.

1. Use key [↑] or [↓] to select ‘PRINT MC AND IP?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.17 Reprint Receipt by [CASH] Key?

This function is to choose whether to allow re-printing the last receipt by press [CASH] key.

1. Use key [↑] or [↓] to select ‘REPRINT RECEIPT BY [CASH] KEY?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

Note:

1. **The copy receipt is not non-sale receipt, so whether to set the item ‘RECEIPT SET/PRINT NON-**

SALE RECEIPT?’ to ‘YES’ won’t affect this function.

- 2. If you set this item to YES, you may set the copy times. (Refer to chapter 9.6.18)**
- 3. You can reprint receipt even if the clerk logout.**

9.6.18 Set Copy Receipt Times

This function is to set the allowable copy times of one receipt.

- Use key [↑] and [↓] to select the item ‘SET COPY RECEIPT TIMES’, and press [CASH] key to enter.
- After enter this function, the system will prompt: <SET COPY RECEIPT TIMES (1~99)>, input one number range from 1 to 99, and press [CASH] to save your setting.

9.6.19 Copy Receipt Even if the QTY is 0?

This function is to choose whether to allow copy receipt even if the quantity is 0.

- Use key [↑] and [↓] to select the item ‘COPY RECEIPT EVEN IF THE QTY IS 0?’, and press [CASH] key to enter.
- Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.20 Only Reprint Header and Totalizer?

This function is to set whether to reprint header and totalizer only.

- Use key [↑] and [↓] to select “ONLY REPRINT HEADER AND TOTALIZER?” item. Press [CASH] to enter.
- Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.21 Print Login/Logout Message?

This function is to choose whether to print receipt when clerk login/logout.

- Use key [↑] and [↓] to select “PRINT LOGIN/LOGOUT MESSAGE?” item. Press [CASH] to enter.
- Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.22 Void PLU Print Strikethrough?

This function is to set whether to print strikethrough on PLU when voiding sales.

- Use key [↑] and [↓] to select “VOID PLU PRINT STRIKETHROUGH?” item. Press [CASH] to enter.
- Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.23 Print hold receipt

This function is to set whether to print receipt when holding bill.

- Use key [↑] and [↓] to select “PRINT HOLD RECEIPT?” item. Press [CASH] to enter.
- Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.24 Print Sale Receipt?

This function is to choose whether to open sales receipt printing.

- Use key [↑] or [↓] to select ‘PRINT SALE RECEIPT?’ item, press key [CASH] to enter this function.

2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.25 Print Non-Sale Receipt?

This function is to choose whether to open non-sale receipt printing.

1. Use key [↑] or [↓] to select ‘PRINT NON-SALE RECEIPT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.26 Print Report?

This function is to choose whether to open reports printing.

1. Use key [↑] or [↓] to select ‘PRINT REPORT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.27 Print Bill?

This function is to set whether to print bill.

1. Use key [↑] or [↓] to select ‘PRINT BILL?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.28 Print Barcode?

This function is to choose whether to print PLU barcode.

1. Use key [↑] or [↓] to select ‘PRINT BARCODE?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.29 Print Invoice No. on Receipt?

This function is to choose whether to print the invoice number on sales receipt. The format of invoice number is ‘XXX + MC NO (12-digit) + DATE (6-digit) + RECEIPT NO (4-digit)’. ‘XXX’ is the invoice code, you can set it in the item ‘SET INVOICE’ (refer to chapter 9.6.32); ‘MC NO’ is the 12-digit machine number, you can choose whether to print it in invoice number (refer to chapter 9.6.30); ‘DATE’ is the 6-digit number which indicates date, month and year; ‘RECEIPT NO’ is the 4-digit receipt number, you can choose whether to print it in invoice number (refer to chapter 9.6.31).

1. Use key [↑] or [↓] to select the item ‘PRINT INVOICE NO. ON RECEIPT?’, and press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.30 Print MC on Invoice?

This function is to choose whether to print machine number in invoice number.

1. Use key [↑] or [↓] to select ‘PRINT MC ON INVOICE?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.31 Print Receipt No. on Invoice?

This function is to choose whether to print receipt number in invoice number.

1. Use key [↑] or [↓] to select ‘PRINT RECEIPT NO ON INVOICE?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

Note: if you set this item to ‘YES’, and set the item ‘PRINT INVOICE NO ON RECEIPT?’ to ‘YES’, then the receipt number won’t be separately printed on the receipt again.

9.6.32 Set Invoice

This function is to set the content of the first three digits in invoice number.

1. Use key [↑] or [↓] to select ‘SET INVOICE’ item, press key [CASH] to enter this function.
2. System prompts: <INPUT INVOICE NO.>, input the 3-digits invoice code (can be letter or number, please refer to chapter 8 for ‘HOW TO INPUT CHARACTER’), and then press [CASH] key to confirm.

9.6.33 Print Date on Invoice?

This function is to set whether to print date on invoice.

1. Use key [↑] or [↓] to select ‘PRINT DATE ON INVOICE?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.34 Print Define Store Machine No.(SMS)?

This function is to set whether to print store machine serial number on receipt.

1. Use key [↑] or [↓] to select ‘PRINT DEFINE STORE MACHINE NO.(SMS)?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.35 Print Totals QTY on Receipt?

This function is to set whether to print total quantity on receipt.

1. Use key [↑] or [↓] to select ‘PRINT TOTALS QTY ON RECEIPT?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.36 Stored Receipts All Print?

This function is to set whether to print all stored receipt.

1. Use key [↑] or [↓] to select ‘STORED RECEIPTS ALL PRINT?’ item, press key [CASH] to enter.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.37 Print the All Void Item in the Receipt?

This function is to set whether to print all void item in the receipt.

1. Use key [↑] or [↓] to select ‘PRINT THE ALL VOID ITEM IN THE RECEIPT?’ item, press key [CASH] to enter.

2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.38 Print Total Barcode?

This function is to set whether to print total barcode.

1. Use key [↑] or [↓] to select ‘PRINT TOTAL BARCODE?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.39 Print Bill Item No.?

This function is to set whether to print bill item number.

1. Use key [↑] or [↓] to select ‘PRINT BILL ITEM NO.?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.6.40 Font Set

9.6.40.1 Lengthen Multiple for Printing Font

This function is to set the font size.

1. Use key [↑] or [↓] to select “LENGTHEN MULTIPLE FOR PRINTING FONT” item, press key [CASH] to enter this function.
2. After system prompts: , input a digit which ranges from 0 to 4. “0” represents the smallest font, and “4” represents the largest font.
Press [CASH] to confirm your setting.

9.6.40.2 Set Elongate Times of Time Printing in Receipt

Here you can set the date and time’s size, which is printed on the receipt.

1. Use key [↑] or [↓] to select “SET ELONGATE TIMES OF TIME PRINTING IN RECEIPT” item, press [CASH] to enter.
2. System prompts: <INPUT DATE-TIME HEIGHT (0~4)>, 0 is the smallest size, and 4 is the largest size. Input the size number, which is range from 0 to 4, and press key [CASH].

9.6.40.3 Enlarge Payment Message?

Set whether to enlarge the printing font of payment message or not.

1. Use key [↑] or [↓] to select “ENLARGE PAYMENT MESSAGE” item, and then press [CASH] to enter.
2. Use key [↑] or [↓] to select “YES” or “NO”, and then press [CASH] to confirm.
The default setting is “NO”.

9.7 Member Set

9.7.1 Member Card Format

Generally, the member card has a fixed format. You need to set the fixed digits as a format. When customers use member card payment, system will identify the validity of the member card according to the member card format. **E.g.** Set 360003169 as the member card format. A card whose id is 360003169**** can be identified as a valid member card. It can prevent using wrong or phony member cards when selling.

1. Use key [↑] or [↓] to select ‘MEMBER CARD FORMAT’ item, press [CASH] key to enter.
2. System prompts: <INPUT MEMBER CARD FORMAT>, input the fixed member number, and then press [CASH] key to save the setting.

9.7.2 Member Card Check?

Open this flag, you can check whether the member card number is in the valid zone.

1. Use key [↑] or [↓] to select “MEMBER CARD CHECK?” item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.
The default setting is “NO”.

9.7.3 Manual Input Member Card No.?

This function is to choose whether to allow inputting member card number manually.

1. Use key [↑] or [↓] to select ‘MANUAL INPUT MEMBER CARD NO.?’ item, press key [CASH] to enter this function.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.8 Remark set

9.8.1 Set PLU Remark name

There are 60 PLU remark name can be set totally, such as mild spicy, medium-done and high sugar. Input remark index ranging from 1~60, and remark name as system prompts, and press key [CASH] to confirm.

9.8.2 Print PLU Remark?

This item is used to set whether to print PLU remark on the receipt, which can be convenient for cook to prepare meal according to customers’ need. If there is a need to print the receipt in kitchen printer, please enable the function ‘KITCHEN PRINT RECEIPT AFTER CHECK OUT?’ under the menu ‘CLERK OPERATION’ (refer to chapter 9.2).

9.9 Option of Clear Report

Use key [↑] or [↓] to choose an option of clear report, then press key [CASH] to enter. Input number 1 or 0 to select ‘YES’ or ‘NO’.

No.	Item	Description
1	FORCE CLEAR Z DAILY REPORT EVERYDAY?	Whether to force to clear Z daily report every day?
2	FORCE CLEAR MONTHLY REPORT EVERYDAY?	Whether to force to clear monthly report every day?
3	PRN TIME REP WHEN CLEAR DAILY REP?	Whether to print time report when clearing daily report?

4	CLEAR TIME REP WHEN CLEAR DAILY REP?	Whether to clear time report when clearing daily report?
5	PRN DEP. REP WHEN CLEAR DAILY REP?	Whether to print department report when clearing daily report?
6	CLEAR DEP. REP WHEN CLEAR DAILY REP?	Whether to clear department report when clearing daily report?
7	PRN PLU REP WHEN CLEAR DAILY REP?	Whether to print PLU report when clearing daily report?
8	CLEAR PLU REP WHEN CLEAR DAILY REP?	Whether to clear PLU report when clearing daily report?
9	PRN PLU RTN REP WHEN CLEAR DAILY REP?	Whether to print PLU return report when clearing daily report?
10	CLEAR PLU RTN REP WHEN CLEAR DAILY REP?	Whether to clear PLU return report when clearing daily report?
11	CLEAR SALES GRANDTOTAL WHEN CLEAR DAILY REP?	Whether to clear sales grandtotal when clearing daily report?
12	RESET RECEIPT NO WHEN CLEAR DAILY REP?	Whether to reset receipt number when clearing daily report?
13	RESET Z1 COUNT WHEN CLEAR DAILY REP?	Whether to reset Z1 count number when clearing daily report?

9.10 Receipt Inquire

Note: The receipt you inquire is not non-sale receipt, so whether to set the item ‘RECEIPT SET/PRINT NON-SALE RECEIPT?’ to ‘YES’ won’t affect this function below.

9.10.1 Inquire Receipt by Serial No.

This function is to inquire receipt by serial number.

1. Use [↑] or [↓] to select ‘INQUIRE RECEIPT BY SERIAL NO.’, press [CASH] key to enter.
2. System prompts :< SERIAL NO>, input serial number of the receipt you want to inquire and press key [CASH] to inquire.

9.10.2 Inquire Receipt by Receipt No.

This function is to inquire receipt according to receipt number.

1. Use [↑] or [↓] to select ‘INQUIRE RECEIPT BY RECEIPT NO.’, press [CASH] key to enter.
2. System prompts :< INPUT NO>, input receipt number of the receipt you want to inquire and press key [CASH] to inquire.

9.10.3 Inquire Daily Report by Z1

This function is to inquire daily report by Z number.

1. Use [↑] or [↓] to select ‘INQUIRE DAILY REPORT BY Z1.’, press [CASH] key to enter.
2. System prompts :< INPUT Z1 COUNT>, input Z number of the receipt you want to inquire and press key [CASH] to inquire.

9.10.4 Print PLU List

This function is to print PLU information.

1. Use [↑] or [↓] to select 'PRINT PLU LIST', press [CASH] key to enter.
2. System prompts: <INPUT DEP NUM TO PRN (0 ALL PRN)>, input department number that the PLU to print belongs, and press key [CASH] to print. If input 0, ECR will print PLU that in all departments. You can press [FEED] key to stop printing.

9.11 Barcode Set

9.11.1 13 Code Type

This cash register supports 13 digits EAN-13 code and 8 digits EAN-8 code. For EAN-13 code, when the first digit of barcode is 2, it is defaulted as inner barcode. Generally, the last digits used for checksum. Ten types inner barcode starting with 20~29 can be selected from 65 types of barcode.

1. Use key [↑] or [↓] to select '13 CODE TYPE' item, and press key [CASH] to enter.
2. After system prompts: <FIRST 2 CODE>, input first 2 digits of code, press [CASH] key to confirm.
3. After system prompts: <BARCODE TYPE (0~64)>, input barcode type, press [CASH] key to save the setting.

9.11.2 Need to Verify EAN-13 Checksum?

This item is to set whether need to verify EAN-13 checksum.

1. Use key [↑] or [↓] to select the item 'NEED TO VERIFY EAN-13 CHECKSUM?', and press [CASH] key to enter.
2. Use key [↑] or [↓] to select "YES" or "NO", and press [CASH] to confirm.

9.11.3 Set Bar Code Type

This item is to set Bar code type.

1. Use key [↑] or [↓] to select "Set Barcode Type" item, press [CASH].
2. After system prompts: <Set Barcode Type (7~9, 27~29, 30~32, 40~42, 99,100)>, input barcode type, press [CASH] to save the setting.

9.11.4 13 Code as Goods Number?

This item is to set whether to use 13 code as goods number.

1. Use key [↑] or [↓] to select the item '13 CODE AS GOODS NUMBER?', and press [CASH] key to enter.
2. Use key [↑] or [↓] to select "YES" or "NO", and press [CASH] to confirm.

9.12 Other

9.12.1 Set Rounding Table

1. Use key [↑] or [↓] to select 'SET ROUNDING TABLE' item, press key [CASH] to enter this function.
2. System prompts: <ROUND FLAG (0~2)>, input the number between 0~2, and press [CASH].

- System prompts: <INPUT ROUND TABLE NO (0-5)>, input the number between 0~5, and press [CASH] key to confirm.

	0	1	2	3	4	5	6	7	8	9	Original numbers
0	0	1	2	3	4	5	6	7	8	9	Rounded numbers if you input 0
1	0	0	0	5	5	5	5	5	10	10	Rounded numbers if you input 1
2	0	5	5	5	5	5	10	10	10	10	Rounded numbers if you input 2
3	0	0	0	0	0	10	10	10	10	10	Rounded numbers if you input 3
4	0	10	10	10	10	10	10	10	10	10	Rounded numbers if you input 4
5	0	0	0	0	0	5	5	5	5	5	Rounded numbers if you input 5

9.12.2 Set Voucher Circulation Rate

Note: before entering this function, you must set the item ‘PAYMENT/USE VOUCHER/LIMITED PAYMENT?’ to ‘YES’.

- Use key [↑] or [↓] to select ‘SET VOUCHER CIRCULATION RATE’ item, press [CASH] to enter.
- System prompts: <SET VOUCHER CIRCULATION RATE>, input the voucher circulation rate, and then press [CASH] key to confirm.

9.12.3 AC Loss Alarm?

Use key [↑] or [↓] to select “AC LOSS ALARM?” item, press [CASH], and then choose “YES” or “NO”, press [CASH] to confirm. The default setting is “YES”.

9.12.4 LCD Contrast

This function is preset to adjust the LCD’s definition.

- Use key [↑] or [↓] to select “LCD CONTRAST” item, press [CASH].
- System prompts: <PLS INPUT LCD DARK (1~7)>. There are 7 levels of LCD contrast, 1 represents that highest lightness display, and 7 represents the lowest lightness display.
- Input a digit ranges from 1 to 7, and press [CASH] to save the setting. The default setting is 4.

9.12.5 LCD Refurbish

This function is preset to set the frequency of LCD refurbish.

- Use key [↑] or [↓] to select “LCD REFRUBISH” item, press [CASH].
- System prompts: <LCD REFURBISH (0~255)>. 0 represents no refurbish, and 255 represents the LCD refurbishes every 255 seconds.
- Input a digit ranges from 0 to 255, and press [CASH] to save the setting.

9.12.6 Key Speed

This function is to set key speed.

- Use key [↑] or [↓] to select “KEY SPEED” item, press [CASH].
- System prompts: < KEY SPEED (1~3)>. 1 represents slow and 3 represents fast.

9.12.7 Petrol Station Function

1. Use key [↑] or [↓] to select the item ‘PETROL STATION FUNCTION’, and press [CASH] key to enter.
2. System prompts: <INPUT PETROL COUPON AMOUNT>, input the petrol coupon amount, and then press [CASH] key to confirm.

E.g.: set the petrol coupon amount as Rs.10

Press [1][0][CASH]

Note: when you sell PLU whose type is set as ‘OIL’, if the PLU price is higher than the petrol coupon amount you set in this function, the LCD will prompt you to input customer’s name and vehicle number.

9.12.8 Set message

1. Use key [↑] or [↓] to select the item ‘SET MESSAGE’, and press [CASH] key to enter.
2. System prompts: <MESSAGE 1>, input the customer’s name (the default setting is “CUSTOMER”), and then press [CASH] key to confirm.
3. System prompts: <MESSAGE 2>, input the customer’s vehicle number (the default setting is “VEHICLE#”), and then press [CASH] key to confirm.

9.12.9 Power On Await Set

This function is to set whether ECR standby when powering on.

1. Use key [↑] or [↓] to select the item ‘Power on Await Set’, and press [CASH] key to enter.
2. Use key [↑] or [↓] to select “YES” or “NO”, and press [CASH] to confirm.

9.12.10 Idle Time Set

This function is to set idle time of the ECR. Failing any operation within the idle time set, ECR will enter standby mode.

9.12.11 Key Sound

This function is to set key sound (default 3), ranging from 0~3, 0 indicate silence while pressing keys.

9.12.12 Show Version Information

This function is to show the version of the ECR.

10 FUNCTIONS IN SYSTEM SET MODE

Attention:

1. If transaction has done, Z daily report must be printed before entering SYSTEM SET mode, and clerk need to login again.
2. The machine beeps when an error occurs and the error message 'ERR X' is displayed. Please refer to chapter 14 for details.

Following items can be set in S mode:

- ✓ CHANGE TO TRAINING MODE (shown in user mode)/CHANGE TO USER MODE (shown in training mode)
- ✓ CHANGE TO TAX MODE (shown in user mode, it will disappear in tax mode)
- ✓ MACHINE NO. PROGRAM
- ✓ SET SALEMAN/WAITER
- ✓ OPTION OF DATA UPLOAD
- ✓ CLEAR SALES DATA
- ✓ SET LOCAL CURRENCY SYMBOL
- ✓ SET RECEIPT TYPE
- ✓ DATE AND TIME SET
- ✓ SET ALARM POINT FOR TIME DIFFERENCE
- ✓ NETWORK SET
- ✓ ORGANIZE DATA
- ✓ EXTERNAL DEVICE SET
- ✓ FISCAL SET (shown in tax mode)

Press [CLERK] key to shift to SYSTEM SET mode, press [CASH] key to enter. Input the manager number and password, and then press key [CASH] to enter. (If the clerk has the purview of 'SYSTEM SET', then here no need to input manager number and password.)

Press key [↑] or [↓] to select the item you want to set in SYSTEM SET mode.

In SYSTEM SET mode, define some function keys as below:

[↑]	Select the previous item
[↓]	Select the next item
[CASH]	Confirm
[C]	Clear current input / Exit System mode

10.1 Change to Training Mode/Change to User Mode Setting

If you are in USER mode, this item will be shown as 'CHANGE TO TRAINING MODE'; if you are in TRAINING mode, this item will be shown as 'CHANGE TO USER MODE'.


1. Use key [↑] or [↓] to select 'CHANGE TO TRAINING MODE' or 'CHANGE TO USER MODE' item, press key [CASH].
2. After system prompts: <INPUT ECR NO (LAST 8 DIGIT)>, input the 8-digit machine number which is marked on the receipt, and then press [CASH] to confirm.

Wait for several seconds, system comes back to REG mode, and the clerk need to login again.

Note: all sales data in training mode won't be stored.

10.2 Change to Tax Mode

1. Use key [↑] or [↓] to select ‘CHANGE TO TAX MODE’ item, press key [CASH] to enter this function.
2. After system prompts: <INPUT ECR NO (LAST 8 DIGIT)>, input the machine number which is marked on the receipt. Then press [CASH] to confirm. Wait for several seconds, system comes back to REG mode, and a clerk need to login again.



Note: if you want to transfer to no tax mode when you are in tax mode, you need to transfer to training mode first, and then transfer to user mode. At this time, you will be in the non-tax mode.

10.3 Machine No. Program

This function is to set user-defined machine number. This function is useful for differentiating several cash registers.

1. Use key [↑] or [↓] to select ‘MACHINE NO. PROGRAM’ item, and then press key [CASH] to enter.
2. System prompts: <INPUT MACHINE NO. (4 DIGIT)>, input a 4-digit number as the machine number, and then press [CASH] key to confirm.
3. If you want to print the self-defined machine number on the receipt, the flag ‘RECEIPT SET/PRINT DEFINE STORE MACHINE NO.?’ in SET mode must be set “YES”. And enable the function ‘SET/RECEIPT SET/ PRINT MC AND IP’.

INV. NO.:VBF7FT000001
 DATE:10/04/23 14:13 NO:000001
 NAME DIS PRICE QTY AMOUNT

 Lemon 10.00 1 10.00 A

 Total Amount ₹10.00
 NetAmount ₹10.00

 TOTAL QTY 1 ₹10.00
 CASH ₹10.00
 SMC:65535 IP:192.168.16.207
 CLERK:1

Here shows the user-defined machine number. ←

10.4 Set Salesman/ Waiter

1. Use [↑] or [↓] key to select ‘ Set Salesman/ Waiter’ item, press [CASH] to enter.
2. System prompts: <IDX>. Input the Salesman’s or Waiter’s number, and then press [CASH] to confirm.
3. System prompts: <NAME>. Input the Salesman’s or Waiter’s name, and then press [CASH] to confirm.

10.5 Option of Data Upload

Item	Description
UPLOAD TRANSACTION TO PC?	Whether to allow uploading the trade detail to PC?
PC ONLINE MODE TO REACH RECEIPTS? (Ethernet Mode)	Whether to notify PC to upload sales data? (Note: set the item “SYSTEM SET /OPTION OF DATA UPLOAD/UPLOAD TRANSACTION TO PC?” to “YES” first.)
SEND ALLVOID RECEIPT TO PC?	Whether to allow sending all void receipt to PC. (Note: set the item “SYSTEM SET /OPTION OF DATA UPLOAD/UPLOAD TRANSACTION TO PC?” to “YES” first.)
UPLOAD BILL WISE SUMMARY TO PC?	Whether to upload the transaction bill wise detailed report and summary report.

10.6 Clear Sales Data

10.6.1 Erase ECR Data

This function is to erase all sales data in the cash register, you should do this operation cautiously.

1. Use key [↑] or [↓] to select ‘ERASE ECR DATA’ item, press [CASH].
2. The system prompts: <WARNING!! ALL SALE DATA WILL LOST, INPUT 777 IF CONFIRM>. If you input 777, and press [CASH], all sales data in the cash register will be erased.

10.6.2 Set the Sales Data Which Will Be Cleared

1. Use key [↑] or [↓] to select ‘SET THE SALES DATA WHICH WILL BE CLEARED’ item, press [CASH] to enter. There is submenu displayed as followings:

<p>CLEAR TRANSACTION CLEAR PLU STOCK CLEAR TABLE DATA CLEAR UNPAID TABLE DATA CLEAR VOID DATA CLEAR TERM DAILY DATA CLEAR PLU TERM DATA CLEAR PROFIT DATA CLEAR OLD Z DAILY REPORT CLEAR BILL WISE SUMMARY DATA</p>
--

2. Use key [↑] or [↓] to select each item, press [CASH] key to enter.
3. Select 'YES' or 'NO' to decide whether to clean the chosen data.

10.6.3 Clear Sales Data

1. Use key [↑] or [↓] to select 'CLEAR SALES DATA' item, press [CASH].
2. The system prompts: <WARNING!! ALL SALE DATA WILL LOST, INPUT 555 IF CONFIRM>. If you input 555, and press [CASH], all sales date which you choose to clear in 'SET THE SALES DATA WHICH WILL BE CLEARED' will be erased.

10.7 Set Local Currency Symbol

1. Use key [↑] or [↓] to select 'SET LOCAL CURRENCY SYMBOL' item, press [CASH].
2. The system prompts: <Local Currency Symbol>, set local currency symbol and then press key [CASH] to confirm.

10.8 Set Receipt Type

There are two types of receipt format in the system for choice.

1. Use key [↑] or [↓] to select 'SET RECEIPT TYPE' item, and then press [CASH].
2. System prompts: <RECEIPT TYPE (0.REGULAR 1.IRREGULAR)>, input 0 or 1 and then press [CASH] to select a type.

10.9 Date and Time Set

10.9.1 Set Date

1. After system prompts: <DATE (DDMMYYYY)>, input date, and press [CASH] to confirm.
2. Date format is DDMMYYYY. DD indicates day, data range from 01 to 31; MM indicates month, data range from 01 to 12; YYYY indicates year.

Example: set date 16/08/2010

press [1][6][0][8][2][0][1][0][CASH]

10.9.2 Time Set

1. After system prompts: <TIME (HHMMSS)>, time can be input. Press [CASH] to confirm.
2. Time format is HHMMSS. HH is hour ranging from 00 to 23. MM is minute ranging from 00 to 59. SS is second ranging from 00 to 59.

Example: set time 14:10:30

press [1][4][1][0][3][0][CASH]

10.9.3 Set Daily Time Error

This function is used to set the daily time difference between ECR and the standard time (ranging from -180s to 180s). Time difference compensation will be daily operated by system automatically. Negative data means 'slow', and positive data means 'fast'. **E.g.** The time difference is -10s. It means the time of ECR is 10s slower than the standard time.

1. Use key [↑] or [↓] to choose the item 'SET DAILY TIME. ERROR', and then press [CASH] key to

enter.

2. System prompts: < DAILY TIME ERROR (s/d -180S ~ +180S)>, input the daily time difference (-180 to 180), and then press [CASH] to confirm.

10.10 Set Alarm Point for Time Difference

This function is to set the warning time. If the time difference between the ECR and PC is over the warning value, the machine will give an alarm.

1. Use key [↑] or [↓] to select ‘SET ALARM POINT FOR TIME DIFFERENCE’ item, press [CASH].
2. System prompts: <INPUT WARNING TIME (MINUTE)>, and input the warning minutes here, and click [CASH] to save your setting.

10.11 Network Set

10.11.1 Switch Net Work Type

1. Use key [↑] or [↓] to select ‘Switch Net Work Type’, and press key [CASH].
2. System prompts: < NET WORK TYPE (0: ETHERNET 1:ADSL)>, input 0 or 1 to select network type, and press [CASH] to confirm.

10.11.2 Set ECR IP

1. Use key [↑] or [↓] to select ‘Set ECR IP’, and press key [CASH].
2. System prompts: < Internet Protocol (TCP/IP)>, press [CASH] to confirm.

① Local IP Address Source

1. Use key [↑] or [↓] to select ‘Local IP Address Source’, and press key [CASH].
2. System prompts: < 0: Manual Set 1:Obtain automatically>, input 0 or 1 to set obtain Local IP Address manually or automatically, press [CASH] to confirm.

If selecting “0: Manual Set”, you need to set following steps ② ③ ④ ⑥⑦⑧ ;

If selecting “1:Obtain automatically”, you only need to set following steps ⑤⑧ ;

② Local IP Address

1. Use key [↑] or [↓] to select ‘Local IP Address’, and press key [CASH].
2. System prompts: < IP NO, USE [.] CLEFT>, input Local IP Address manually, press [CASH] to confirm.

③ Subnet Mark

1. Use key [↑] or [↓] to select ‘Subnet Mark’, and press key [CASH].
2. System prompts: < IP NO, USE [.] CLEFT>, input Subnet Mark manually, press [CASH] to confirm.

④ Default Gateway

1. Use key [↑] or [↓] to select ‘Default Gateway’, and press key [CASH].
2. System prompts: < IP NO, USE [.] CLEFT>, input Default Gateway manually, press [CASH] to confirm.

⑤ DNS Server Address Source

1. Use key [↑] or [↓] to select ‘DNS Server Address Source’, and press key [CASH].
2. System prompts: < 0: Manual Set 1:Obtain automatically>, input 0 or 1 to set obtain DNS Server Address manually or automatically, press [CASH] to confirm.

If selecting “0: Manual Set”, you need to set following steps ⑥⑦.

⑥ Preferred DNS Server

1. Use key [↑] or [↓] to select ‘Preferred DNS Server’, and press key [CASH].
2. System prompts: < IP NO, USE [.] CLEFT>, input Preferred DNS Server manually, press [CASH] to confirm.

⑦ Alternate DNS Server

1. Use key [↑] or [↓] to select ‘Alternate DNS Server’, and press key [CASH].
2. System prompts: < IP NO, USE [.] CLEFT>, input Alternate DNS Server manually, press [CASH] to confirm.

⑧ Set ECR Port

- Use key [↑] or [↓] to select ‘Set ECR Port’, and press key [CASH].
- System prompts: < INPUT PORT (3000~5000) >, input ECR port (e.g. **5002**), press [CASH] to confirm.

10.11.3 Set ADSL User Name and Password

1. Use key [↑] or [↓] to select ‘Set ADSL User Name and Password’, and press key [CASH].
2. System prompts: < ADSL ID >, set ADSL user name, press [CASH] to confirm.
3. System prompts: < ADSL PASSWORD >, set ADSL password, press [CASH] to confirm.
4. System prompts: < CONFIRM PASSWORD >, input ADSL password again, press [CASH] to confirm.

10.11.4 Set Host IP

1. Server address source

1. Use key [↑] or [↓] to select ‘Server address source’, and press key [CASH].
2. System prompts: < 0: Use IP Address Set 1: Use Domain Name Set >, input 0 or 1, and press [CASH] to confirm.

If selecting “0: Use IP Address Set”, you need to set Server IP address;

If selecting “1: Use Domain Name Set”, you need to set Domain Name;

2. Domain Name

1. Use key [↑] or [↓] to select ‘Domain Name’, and press key [CASH].
2. System prompts: <Input Domain Name >, input Domain Name, and press key [CASH] to confirm.

3. Server IP Address

1. Use key [↑] or [↓] to select ‘Server IP Address’, and press key [CASH].
2. System prompts: <Input Server IP Address >, input Server IP Address (e.g. 192.168.1.88), and press key [CASH] to confirm.

10.12 Organize Data

This function is used to set whether to clear up some useless data such as fragments junk in the memorizer of ECR so that more vacancy is on standby. It will take some time to organize data.

NO.	ITEM	DESCRIPTION	Default Setting
1	ORGANIZE PLU DATA	Whether to organize the PLU data?	NO
2	ORGANIZE STOCK DATA	Whether to organize the stock data?	NO
3	ORGANIZE PLU SALES DATA	Whether to organize the PLU sales data?	NO

10.13 External Device Set

10.13.1 RS232 Device Set

The machine has a RS232 port, which is used to connect the ECR to PC or some peripheral devices.

1. Use key [↑] or [↓] to select 'RS232 DEVICE SET' item, and press key [CASH] to enter this function.
2. System prompts: < RS232 COM (1)>, input COM port No. (1) and press [CASH].

LCD displays:

SCANNER SCALE EXT. LCD KITCHEN PRN DONGLE egame

3. Use key [↑] or [↓] to select the peripheral device, and press key [CASH] to confirm.

10.13.2 Set Scale Type

The cash register can connect to scale. Before using, you need to do this setting.

1. Use key [↑] or [↓] to select 'SET SCALE TYPE' item, press [CASH] to enter this function.
2. LCD displays:

TVSE FTP ANGEL SCALE SNOWREX SCALE EMBEED SCALE HMS SCALE OP SCALE CAS PD

3. Use key [↑] or [↓] to select the scale connected, and press key [CASH] to confirm.

10.13.3 SET KITCHEN PRINTER

ECR can be attached with several kitchen printers.

1. Using communication cable to connect ECR with the kitchen printer via RS232 port.
2. Set the corresponding kitchen printer index under the menu 'SET/ BASIC SET/ DEPARTMENT SET'. Please refer to chapter 9.1.2 for details.
3. Enable the function 'KITCHEN PRINT RECEIPT AFTER CHECK OUT?' under the menu 'SET/CLERK OPERATION' (refer to chapter 9.2), after settling account, kitchen printer will print out the receipt. If there is a need to print the hold bill by kitchen printer, please enable the function

‘KITCHEN PRINT HOLD RECEIPT?’.

4. Enter ‘SYSTEM SET/ EXTERNAL DEVICE SET/SET KITCHEN PRINTER’, and press key [CASH].
5. Select ‘Kitchen Printer’, and press key [CASH].
6. System prompts < Input Kitchen Printer Idx (1~16)>, set the printer index and press key [CASH] to confirm. (Make sure the index set here conform to the printer index set under SET/BASIC SET/ DEPARTMENT SET.)
7. LCD displays types of kitchen printer:

TVSE KL1
TVSE LP3
TVSE PP4X/PP6X
TVSE KP7X
EPSON TM-T88
GP-76xx/80xx Series
GP-586x Series
TVS PRINTER
TVSE KP2X
TVSE PP6XE
TVSE KP7E
TVSE KL1 ETHERNET
TVSE LP1 ETHERNET
SAM SUNG SRP-350
GP-76XX/80XX ETHERNET
GP-586X ETHERNET
TVS PRINTER ETHERNET
ECR
NO USE

8. Use key [↑] or [↓] to select printer type, and press key [CASH] to confirm.
9. Set parameter of the printer as the system prompts.

10.13.4 DONGLE SET

1. Use key [↑] or [↓] to select ‘DONGLE SET’ item, and press [CASH] to confirm.
2. System prompts: < MY SHOP NUM>, set shop number, and press [CASH] to confirm.
3. System prompts: <MY DONGLE IP>, set dongle IP address, and press [CASH] to confirm.

10.13.5 GUEST PAGING SYSTEM SETTING

➤ GUEST PAGING DEVICE SET

1. Select this item, and press key [CASH] to confirm.
2. System prompts <0: WALL DISPLAY 1: GUEST PAGER>, input 0 or 1 to select and press key [CASH] to confirm.

10.14 Fiscal Set


Note: This item will be concealed in user mode. After changing to TAX mode, you can set 'FISCAL SET'.

10.14.1 Tax Rate

1. Use [↑] or [↓] key to select 'TAX RATE' item, and then press [CASH] key to enter.
2. After system prompts: <TAX IDX (1~8)>, input a digit ranging from 1 to 8 (1 for tax A; 2 for tax B; 3 for tax C; 4 for tax D; 5 for tax E; 6 for tax F; 7 for tax G; 8 for tax H), and then press [CASH].
3. System prompts: <TAX FLAG>. Tax flag is marked behind the price on the receipt. For example, you set * as a tax flag. When a PLU with the tax is sold, the tax flag * will be printed behind the price on the receipt. Also, leave a space here, the tax flag will be ignored. (Please refer to chapter 8 for 'HOW TO INPUT CHARACTER'.)
4. System prompts: <TAX NAME>. Input the tax name and then press [CASH]. (Please refer to chapter 8 for 'HOW TO INPUT CHARACTER'.)
5. System prompts: <TAX DEPEND ON TAX? (1. YES 0. NO)>. Input number 1 or 0 to set whether the tax is tax-on-tax.
6. System prompts: <TAX RATE>. Input the tax rate and then press [CASH] to confirm.

Note: 1. Only one type of tax is available for tax-on-tax.

2. Set 'SYSTEM SET/FISCAL SET/ PRINT TAX ON RECEIPT?' to 'YES'.



NAME	DIS	PRICE	QTY	AMOUNT
Lemon		10.00	1	10.00 (A)
Total Amount				₹10.00
NetAmount				₹10.00
TOTAL QTY	1			₹10.00
CASH				₹10.00

INV. NO.:VBF7FT000001
DATE:10/04/23 14:13 NO:000001
SMC:65535IP:192.168.16.207
CLERK:1

10.14.2 Tax Head Line and Tax Tail Line

1. Use key [↑] or [↓] to select the item 'TAX HEAD LINE' or 'TAX TAIL LINE' item, and then press [CASH] to enter.
2. After system prompts: <IDX (1~3)>, input the index of the line you want to edit, press [CASH]. There are totally 3 lines of head message can be set.
3. System prompts: <MSG>. Input the message content, and then press [CASH] key to confirm. (Please refer to chapter 8 for 'HOW TO INPUT CHARACTER'.)

10.14.3 TIN No.

1. Use key [↑] or [↓] to select the item 'TIN NO.', and then press [CASH] to enter.
2. After system prompts: < TIN NO.>, input taxpayer ID number and press [CASH].

10.14.4 Price Including Tax?

This is to set whether the price includes the tax.

1. Use [↑] or [↓] key to select the item 'PRICE INCLUDING TAX?', and then press [CASH] key to enter.
2. Use key [↑] or [↓] to select 'YES' or 'NO', and press key [CASH] to confirm.

10.14.5 Print Report in Spite of Zero Tax?

This is to set whether to print reports even if the tax amount is 0.

- 1 Use key [↑] or [↓] to select the item 'PRINT REPORT IN SPITE OF ZERO TAX?', and press [CASH] key to enter.
- 2 Use key [↑] or [↓] to select 'YES' or 'NO', and press key [CASH] to confirm.

10.14.6 Printing Option

Item	Description
PRINT TERM TIME?	Whether to print term time on report
PRINT VOID AMT?	Whether to print void amount on report
PRINT ALLVOID AMT?	Whether to print all void amount on report
PRINT RTN TOTAL?	Whether to print return total on report
PRINT NOSALE COUNT?	Whether to print no sale count on report
PRINT PROFIT AMT?	Whether to print profit amount on report
PRINT TAXABLE SALE AMT?	Whether to print taxable sale amount on report
PRINT SALES GRANDTOTAL	Whether to print sales grandtotal on report
PRINT TOTAL CASH?	Whether to print total cash amount on report
PRINT TOTAL CREDIT?	Whether to print total credit payment amount on report
PRINT TOTAL CARD?	Whether to print total card payment amount on report
PRINT TOTAL OTHER?	Whether to print total other amount on report
PRINT RETURN CASH?	Whether to print return cash amount on report
PRINT RETURN CARD?	Whether to print return card payment amount on report
PRINT RETURN OTHER?	Whether to print return other amount on report
PRINT CLERK DAILY REPORT?	Whether to print detail sales information of each login clerk on the clerk daily report
PRINT STOCK WHEN PRINT PLU REPORT?	Whether to print stock when print PLU report

10.14.7 Print Tax on Receipt?

This function is used to set whether to print the tax on the receipt.

- 1 Use [↑] or [↓] key to select the item 'PRINT TAX ON RECEIPT?', and then press [CASH] key to enter.
- 2 Use key [↑] or [↓] to select 'YES' or 'NO', and press key [CASH] to confirm.

11 SALES OPERATIONS

Press key [CL] several times until you get to the following interface. Now, you are in REG mode, and all sales operation is in this mode.

```

CLERK: 1

0
    
```

11.1 Display System Message

Method 1

Press key [QTY] to display ECR message in its initial status.

Method 2

Press [CL] key several times until it returns to the initial status, and then press [Set Cashier]. Use [↑] or [↓] key to select “SHOW SYSTEM MSG” item, press [CASH] key to confirm.

```

29/03/2023 17:33
3.392 PT 235E 15G
VBF7FT000001
USER CATERING
192.168.16.207
    
```

```

Printer: 7V176
PWR: 7.4V
Ttemp: 1993
Printer AD:328
    
```

11.2 Receipt Format Description

There are two types of receipt format for choice, the regular one and the irregular one. Enter ‘SET RECEIPT TYPE’ under menu ‘SYSTEM SET’ mode to choose a receipt type. Please refer to chapter 10.8

Regular Type

Description:
NAME—PLU name
DIS—discount rate
PRICE—unit price
QTY—quantity
AMOUNT—total sum

```

INV. NO.:VBF7FT000001
DATE:10/04/23 14:13 NO:000001
NAME DIS PRICE QTY AMOUNT
Lemon 10.00 1 10.00 A
Total Amount ₹10.00
NetAmount ₹10.00
TOTAL QTY 1 ₹10.00
CASH ₹10.00
SMC:65535IP:192.168.16.207
CLERK:1
    
```

Date & Time ←

Irregular Type

<p>Welcome Wish You a Happy Day Pinnacle Technology Corp. +86-592-5710087 www.tvs-e.in</p>		Head message (5 lines)
<p>Pinnacle Technology Corp. +86-592-5710087w ww.tvs-e.in</p>		Tax head lines (3 lines)
<p>RECEIPT</p>		Receipt head description
Invoice number	INV. NO.: VBF7ET000001	
	DATE: 10/04/23 14:00 NO:000001	
Barcode number	1. Apple X90% ₹ 10.80A	Tax flag
<hr/>		
	Total Amount ₹ 10.80	
	NetAmount ₹ 10.80	
<hr/>		
	TOTAL QTY 1 ₹ 11.88	
	CASH ₹ 11.88	
	SMC:65535 IP:0.0.0.0	
	CLERK: 1	Clerk name

11.3 Department Sales

You can divide the commodity to several departments, such as home electro-appliance department, aquatic product department etc. Each department has a default price. For example, price of all the fish in aquatic department is \$10/pc. One fish is sold when you press aquatic department key one time. Of course you can sell \$25 a fish a time, or sell several fish one time, namely, you can sell in sales quantity or sales sum.

E.g.:

Sell at department price

Dept No.
 [3][DEPT.] |
 [4][DEPT.]

(Set 'SET/CLERK OPERATION/MANUAL CHANGE PRICE?' to YES).

Sell at key-in price

Money Dept No.
 [1][PRICE][3][DEPT.]
 [2][PRICE][4][DEPT.]

(Set 'SET/CLERK OPERATION/MANUAL INPUT QTY?' to YES).

Manually input quantity

Qty. multiply Dept. No.
 [2][QTY][3][DEPT.]
 [3][QTY][4][DEPT.]

Settle accounts

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 14:24 NO:000003				
NAME	DIS	PRICE	QTY	AMOUNT
DEP 003		300.00	1	300.00 C
DEP 004		400.00	1	400.00 D
DEP 003		1.00	1	1.00 C
DEP 004		2.00	1	2.00 D
DEP 003		300.00	2	600.00 C
DEP 004		400.00	3	1,200.00 D
Total Amount				₹2,503.00
NetAmount				₹2,503.00
TOTAL QTY 9		₹2,503.00		
CASH		₹2,503.00		
SMC:65535IP:192.168.16.207				
CLERK:1				

11.4 Fixed Amount Sale

When you sell weighing PLU or oil (set the PLU type as 'WEIGHT CARGO' or 'OIL', please refer to chapter 13.1.2) with the given total price, you can use [Fixed-Amount] key to sell. **For example**, some apples have been weighed by the label scale, and the total price is given on the label, or sometimes a customer comes to a petrol station to buy oil with a given total sum, the clerk can use [Fixed-Amount] key to input the total sum to sell them, and the weight or amount will be counted automatically.

E.g. 1:

Fixed amount sales [SHIFT][Fixed-Amount]
 Input fixed amount [2][0][0]
 Confirm [CASH]
 Sell weight cargo [9] [PLU]
 Settle accounts [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 14:39 NO:000004				
NAME	DIS	PRICE	QTY	AMOUNT
PLU 9		100.	2.000L	200.00 A
				₹200.00
				₹200.00
				₹200.00
				₹200.00
SMC:65535IP:192.168.16.207				
CLERK:1				

The amount of oil will be counted automatically and shown on the receipt.

11.5 PLU Sales

PLU is the merchandize. Every PLU has its price and barcode. Input barcode number when selling PLU. You can manually input PLU quantity and price while selling (set ‘SET/CLERK OPERATION/MANUAL CHANGE PRICE?’ and ‘SET/CLERK OPERATION/MANUAL INPUT QTY?’ to YES).

E.g.1: Sell at preset PLU price

PLU barcode PLU item
 [3][PLU]
 [4][PLU]

Sell at key-in price

Money Unit price PLU barcode PLU item
 [1][PRICE][3][PLU]
 [2][PRICE][4][PLU]

Manually input quantity

Qty. multiply PLU barcode PLU item|
 [2][QTY][3][PLU]
 [3][QTY][4][PLU]

Settle accounts

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:02 NO:000005				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Dress		41.00	1	41.00
Calotte		1.00	1	1.00
Dress		2.00	1	2.00
Calotte		30.00	2	60.00
Dress		41.00	3	123.00
Total Amount				₹257.00
NetAmount				₹257.00
TOTAL QTY			9	₹257.00
CASH				₹257.00
SMC:65535IP:192.168.16.207				
CLERK:1				

E.g.2: Sell several same PLU

Note: Set “CLERK OPERATION/SUMMARY QYT FOR THE SAME PLU SALES?” and “CLERK OPERATION/ PRINT RECEIPT AFTER CHECK OUT?” in SET to “YES”. (Refer to chapter 9.2.)

PLU barcode, PLU item|
 [2][PLU]
 [2][PLU]

Settle accounts

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:38 NO:000003				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	2	40.00 B
Total Amount				₹40.00
NetAmount				₹40.00
TOTAL QTY			2	₹40.00
CASH				₹40.00
SMC:65535IP:192.168.16.207				
CLERK:1				

2. “CLERK OPERATION/SUMMARY QYT FOR THE SAME PLU SALES?” in SET mode is set “NO”. (Refer to chapter 9.2.)

PLU barcode, PLU item
 [2][PLU]
 [2][PLU]

Settle accounts

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:39 NO:000004				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Soursop		20.00	1	20.00 B
Total Amount				₹40.00
NetAmount				₹40.00
TOTAL QTY			2	₹40.00
CASH				₹40.00
SMC:65535IP:192.168.16.207				
CLERK:1				

Note:

1. If you select the item “SET MENU LEVEL/CHOICE PRICE” in “SET MODE” or “OTHER FUNCTION”, there will be 4 types of price for each PLU, use [↑] [↓] key to select the price, and press [Enter] key to confirm.
2. The ECR can remember the key-in price temporarily. If you sell one PLU as key-in price, then if you sell the PLU again, its price is still the value you just key-in. Until you do other sales operation (for example, sell another PLU), then the price will come back.

11.6 Discount Operation

● -% Discount Operation

Discount rate range is 0.01%~99.99%.

Note: Before you perform PLU discount operation, please set the “DISCOUNT SET/PLU MANUAL DISCOUNT?” to “YES” in “SET” mode.

E.g. 1:

PLU discount

PLU No. rate of -%
[4][PLU][1][0][-%]

PLU discount|

PLU barcode single item discount rate -%
[3][PLU][1][5][-%]

Settle accounts

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:42 NO:000001				
NAME	DIS	PRICE	QTY	AMOUNT
Dress		41.00	1	41.00
	-10.00%			-4.10
Calotte		30.00	1	30.00
	-15.00%			-4.50
Total Amount				₹62.40
NetAmount				₹62.40
TOTAL QTY 2				₹62.40
CASH				₹62.40
SMC:65535IP:192.168.16.207				
CLERK:1				

E.g. 2: Sales PLU

PLU No. [3][PLU]
[4][PLU]

Total discount

Subtotal discount rate -%
[SBTL][1][5][-%]

Settle accounts

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:43 NO:000002				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Dress		41.00	1	41.00
SUBTOTAL				71.00
				-15.00%
				-10.65
Total Amount				₹60.35
NetAmount				₹60.35
TOTAL QTY 2				₹60.35
CASH				₹60.35
SMC:65535IP:192.168.16.207				
CLERK:1				

Note: The operation of “+% SURCHARGE” is similar to the “-% DISCOUNT”.

● - **Discount Operation**

This function is similar to “-% DISCOUNT” function. But “- DISCOUNT” function is a discount of specific sum of amount.

E.g. :

- key [-] transaction
- Sales PLU
 - PLU No. [3][PLU]
 - [4][PLU]
- Display total sum
 - subtotal [SBTL]
- “- DISCOUNT” transaction
 - sum discount [5] [SHIFT][Discount]
- Settle accounts
 - Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:44 NO:000003				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Dress		41.00	1	41.00
SUBTOTAL				71.00
DIS -				-5.00
Total Amount				₹66.00
NetAmount				₹66.00
TOTAL QTY	2			₹66.00
CASH				₹66.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.7 [CE] Key Operation

This function is to cancel the last sales operation before settle accounts.

E.g.:

- Sell PLU
 - [3][PLU]
 - [4][PLU]
- Cancel last department [CE]
- Settle account [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:47 NO:000004				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Dress		41.00	1	41.00
C/E				-41.00
Total Amount				₹30.00
NetAmount				₹30.00
TOTAL QTY	1			₹30.00
CASH				₹30.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.8 [A.VOID] Key Operation

Use key [A.VOID] to cancel a receipt.

E.g.:

- Sell PLU
 - [3][PLU]
 - [4][PLU]
- Cancel all item [SHIFT][A.VOID]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:48 NO:000005				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Dress		41.00	1	41.00
All VOID				
All VOID				₹71.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.9 [VOID] Key Operation

Before settling account, if input is wrong or customer pulls back, the cashier can use key [VOID] to cancel any of the previous items that have been sold.

E.g.:

Sell PLU [2][PLU]
 [3][PLU]

Press key [SHIFT] [VOID], and Use [↑]or [↓] key to select the item to void, and press key [CASH] to confirm.

Input cancel quantity, and press key [CASH] to confirm.

Settle account [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:53 NO:000002				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Calotte		30.00	1	30.00
VOID				
Soursop		20.00	1	-20.00 B
Total Amount				₹30.00
NetAmount				₹30.00
TOTAL QTY 1				₹30.00
CASH				₹30.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.10 Commodity Return

When the account has been settled, the customer finds that he had took the wrong commodity, or he finds that the commodity has been out of storage date. He/she requires returning the commodity.

① Return after settle account

e.g. Sell PLU [2] [PLU]
 [3][PLU]
Settle account [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:54 NO:000003				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Calotte		30.00	1	30.00
Total Amount				₹50.00
NetAmount				₹50.00
TOTAL QTY 2				₹50.00
CASH				₹50.00
SMC:65535IP:192.168.16.207				
CLERK:1				

Return commodity [RETURN]
Input the PLU to return

[2][PLU]
[CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:54 NO:000004				
REFUND RECEIPT				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	-20.00 B
Total Amount				₹20.00
NetAmount				₹20.00
TOTAL QTY 1				₹20.00
CASH				₹20.00
SMC:65535IP:192.168.16.207				
CLERK:1				

② Return part of a commodity

E.g.: sale PLU [3][PLU]
 [2][QTY][2][PLU]

(Note: active the function “SET/CLERK OPERATION /MANUAL INPUT QTY?” first.)

Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:55 NO:000005				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Soursop		20.00	2	40.00 B
Total Amount				₹70.00
NetAmount				₹70.00
TOTAL QTY 3				₹70.00
CASH				₹70.00
SMC:65535IP:192.168.16.207				
CLERK:1				

Return half of PLU2 [RETURN]

Input the part that client want to return
 [1][QTY][2][PLU]
 [CASH]

Note: press [RETURN] key again to exit the RETURN mode.

INV. NO.:VBF7FT000001				
DATE:10/04/23 15:55 NO:000006				
REFUND RECEIPT				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	-20.00 B
Total Amount				₹20.00
NetAmount				₹20.00
TOTAL QTY 1				₹20.00
CASH				₹20.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.11 Receive on Account Operation

Put money into drawer during non-transaction.

E.g.: receive 200 outside of sale
 Tap and hold on the key [R/A]
 System prompts: <R/A AMOUNT>, input [2][0][0][CASH].

DATE:10/04/23 16:04	
R/A	₹200.00
SMC:65535IP:192.168.16.207	
CLERK:1	

11.12 Paid Out Operation

Draw money out of drawer during non-transaction.

E.g.: pay out 200 outside of sale
 Tap and hold on the key [P/O]
 System prompts: <P/O AMOUNT>, input [2][0][0][CASH].

DATE:10/04/23 16:05	
P/O	₹200.00
SMC:65535IP:192.168.16.207	
CLERK:1	

11.13 Cash Transaction

E.g.

Dept. No. [3][DEPT]
[4][DEPT]

Cash payment

[7][5][0] [CASH]

Attention: If there is no input sum of amount, the payment equals the payable sum, giving changes not needed. If input sum greater than the payable sum, system prompts to give changes.

INV. NO.:VBF7FT000001				
DATE:10/04/23 16:05 NO:000001				
NAME	DIS	PRICE	QTY	AMOUNT
DEP 003		300.00	1	300.00 C
DEP 004		400.00	1	400.00 D
Total Amount				₹700.00
NetAmount				₹700.00
TOTAL QTY 2				₹700.00
CASH				₹750.00
CHANGE				₹50.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.14 Card Transaction

E.g.:

Sell PLU [2] [PLU]

Card payment

[SHIFT][CARD]

Settle account [CASH]

INV. NO.:VBF7FT000001				
DATE:10/04/23 16:06 NO:000002				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Total Amount				₹20.00
NetAmount				₹20.00
TOTAL QTY 1				₹20.00
CREDIT				₹20.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.15 Payments Selecting

E.g.:

Sell PLU [2] [PLU]
[3] [PLU]

Payment selecting

Method 1: Press key [SHIFT][Payment] and then use [↑]
or [↓] key to choose pay method, and press key [CASH].

Method 2: input the payment index to choose the corresponding
payment and press key [SHIFT][Payment].

INV. NO.:VBF7FT000001				
DATE:10/04/23 16:06 NO:000003				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Calotte		30.00	1	30.00
Total Amount				₹50.00
NetAmount				₹50.00
TOTAL QTY 2				₹50.00
PAYMENT2				₹50.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.16 Member Card Transaction

Note: If you want to input the member card number manually, the item ‘MEMBER SET / MANUAL INPUT MEMBER CARD NO.’ in SET mode must be set to ‘YES’.

Member card number 3600031691234 for example:
 Input the member card number [3][6][0][0][0][3][1][6][9][1][2][3][4]
 Choose member card payment [SHIFT][MEMBER]
 Sell commodity [2][PLU]
 [3][PLU]
 Settle accounts [CASH]

INV. NO.:VBF7FT000001	DATE:10/04/23 16:11	NO:000005
BUYER GSTIN:3600031691234		
NAME	DIS	PRICE QTY AMOUNT
Soursop		20.00 1 20.00 B
Calotte		30.00
ME PRICE:		27.00 1 27.00
Total Amount		₹47.00
NetAmount		₹47.00
TOTAL QTY 2		₹47.00
CASH		₹47.00
MEMBER: SAVING COST FOR YOU:		₹3.00
SMC:655351P:192.168.16.207		
CLERK:1		

11.17 [Total Qty] key operation

This item is used to sell weight cargo at a fixed amount and weight.

e.g.:

Press key [Total Qty]
 Input amount [1][0][0] [CASH]
 Input weight [5] [CASH]
 Sell weight cargo [1][PLU]
 Settle accounts [CASH]

INV. NO.:VBF7FT000001	DATE:11/04/23 09:09	NO:000001
NAME	DIS	PRICE QTY AMOUNT
Lemon		20 5.000kg 100.00 A
Total Amount		₹100.00
NetAmount		₹100.00
TOTAL QTY 5		₹100.00
CASH		₹100.00
SMC:655351P:192.168.16.207		
CLERK:1		

11.18 Salesman Operation

E.g. a salesman logs in (before transaction has been done)

No.1 salesman logs in:

Press key [SHIFT][PROMOTER]

System prompts: <INPUT SALESMAN/WAITER>,

Input salesman's no.

[1][CASH]

Sell PLU [3][PLU]
 [4][PLU]

Settle accounts [CASH]

INV. NO.:VBF7FT000001	DATE:11/04/23 09:10	NO:000002
WTR:WAITER01		
NAME	DIS	PRICE QTY AMOUNT
Calotte		30.00 1 30.00
Dress		41.00 1 41.00
Total Amount		₹71.00
NetAmount		₹71.00
TOTAL QTY 2		₹71.00
CASH		₹71.00
SMC:655351P:192.168.16.207		
CLERK:1		

Note: After settling account, the promoter logout automatically.

11.19 Hold/ Recall/ Pay

During settling accounts, the client remembers to buy some commodities or order other food. He (she) needs to postpone settling account with the cashier so as to fetch the commodities or food. At this moment it is not necessary for the cashier to press [VOID] to cancel the transaction amount. He can save the transaction amount via the function of “STORE RECEIPT” (**128 receipts at most**). The transaction amount can be recalled via the function of “RECALL RECEIPT” and settling account can be carried on after the client comes back with his newly selected goods.

Note: If you set ‘SET/CLERK OPERATION/HOLD ORDER WITHOUT OPEN TABLE?’ to ‘YES’, it is no need to open a table before sales; otherwise, it is necessary to open a table.

E.g.:

Sell PLU

[2][PLU]

[3][PLU]

Store the bill

[HOLD]

INV. NO.:VBF7FT000001				
DATE:11/04/23 10:01 NO:000014				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Calotte		30.00	1	30.00
SAVE REG				₹50.00
SMC:65535IP:192.168.16.207				CLERK:1

Recall the bill and sell other PLU besides the hold one.

Input the hold number which is printed on the ticket:

[2][4][1] [TABLE]

Sell PLU

[4] [PLU]

Settle account

[CASH]

INV. NO.:VBF7FT000001				
DATE:11/04/23 10:01 NO:000014				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Calotte		30.00	1	30.00
Dress		41.00	1	41.00
Total Amount				₹91.00
NetAmount				₹91.00
TOTAL QTY 3				₹91.00
CASH				₹91.00
SMC:65535IP:192.168.16.207				CLERK:1

11.20 Takeaway Operation

If the customers want to take away the food, you can use this function, please operate as follows:

- ① Press [SHIFT] and [Take Out] key.
- ② Perform sales operation.

E.g.:

Takeaway the food

[SHIFT] [Take Out]

Sell PLU

[2] [PLU]

Use key [↑] or [↓] to select PLU price for takeaway, and press [CASH] to confirm.

(Note: set “SET/BASIC SET/SET MANUAL LEVEL” to “CHOICE PRICE”.)

Settle account

[CASH]

INV. NO.:VBF7FT000001				
DATE:11/04/23 09:55 NO:000009				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Total Amount				₹20.00
NetAmount				₹20.00
TOTAL QTY 1				₹20.00
CASH				₹20.00
SMC:65535IP:192.168.16.207				CLERK:1

11.21 Open a Table

While ordering dishes in a restaurant, the guest needs to open a table which indicates the position, so that waiters can serve conveniently. There are totally 128 different tables can be set in SET mode on ECR. Please follow these steps:

1. Customers pay after they order the meal
 - ① Press [CL] key several times until it returns to the initial status;
 - ② Input table No. and press key [Table] to open table;
 - ③ Perform sales operation.

E.g.: Open table to sell meal

Open table	[1] [Table]
Sell meal	[2] [PLU]
Settle account	[CASH]

INV. NO.:VBF7FT000001
DATE:11/04/23 09:59 NO:000012
TABLE NO: 1
NAME DIS PRICE QTY AMOUNT
Soursop 20.00 1 20.00 B
Total Amount ₹20.00
NetAmount ₹20.00
TOTAL QTY 1 ₹20.00
CASH ₹20.00
SMC:65535IP:192.168.16.207
CLERK:1

2. Customers pay after they finish eating the meal.
 - ① Press [CL] key several times until it returns to the initial status;
 - ② Input table No. and press key [Table] to open table;
 - ③ Perform sales operation.

E.g.: Open table to sell meal

Open table	[2] [Table]
Sell meal	[2] [PLU]
Save bill	[HOLD]

INV. NO.:VBF7FT000001
DATE:11/04/23 09:59 NO:000013
TABLE NO:2
NAME DIS PRICE QTY AMOUNT
Soursop 20.00 1 20.00 B
SAVE REG 2
SAVE REG ₹20.00
SMC:65535IP:192.168.16.207
CLERK:1

Recall the bill when finishing meal:

Input the table No. to recall the stored bill	[2] [Table]
Continue to sell meal if needed	[3] [PLU]
Settle account	[CASH]

INV. NO.:VBF7FT000001
DATE:11/04/23 09:59 NO:000013
TABLE NO:2
NAME DIS PRICE QTY AMOUNT
Soursop 20.00 1 20.00 B
Calotte 30.00 1 30.00
Total Amount ₹50.00
NetAmount ₹50.00
TOTAL QTY 2 ₹50.00
CASH ₹50.00
SMC:65535IP:192.168.16.207
CLERK:1

11.22 Merge Table

This function is to combine two or more tables together to have meal in one table.

Supposed there are 10 tables in a restaurant, and all of which have guest. At this time, there is a need to open a virtual Table 11 for the new guest, and then merge Table 11 into Table 1 where is available seat, to have meal together. After dining, the guests may pay for the food respectively.

E.g.

① the guest at table 1 ordered PLU 2, and hold the bill:

Open a table [1] [Table]
 Sell meal [2] [PLU]
 Hold the bill [HOLD]

```

INV. NO.:VBF7FT000001
DATE:11/04/23 10:03 NO:000015
TABLE NO: 1
NAME DIS PRICE QTY AMOUNT
Soursop 20.00 1 20.00 B
SAVE REG 1
SAVE REG ₹20.00
SMC:65535IP:192.168.16.207
CLERK:1
  
```

② The guest at virtual table 11 ordered PLU 3, and merged table 11 to table 1 to have meal together:

Open a table [11] [Table]
 Sell meal [3] [PLU]
 Hold the bill [HOLD]

```

INV. NO.:VBF7FT000001
DATE:11/04/23 10:03 NO:000016
TABLE NO:11
NAME DIS PRICE QTY AMOUNT
Calotte 30.00 1 30.00
SAVE REG 11
SAVE REG ₹30.00
SMC:65535IP:192.168.16.207
CLERK:1
  
```

③ Merge table [SHIFT] [TABLE]

Merge table 11 to table 1

System prompts :< TRAN OUT TABLE NO>, [11] [CASH]

System prompts :< TRAN IN TABLE NO>, [1] [CASH]

```

DATE:11/04/23 10:04
TRAN OUT TABLE NO:11 ITEM:1
₹30.00
TRAN IN TABLE NO: 1 ITEM:1
₹20.00
TABLE NO:: 1 ITEM:2
₹50.00
SMC:65535IP:192.168.16.207
CLERK:1
  
```

11.23 Split Bill

After dining, the clients at merged table may pay for the food respectively.

E.g.

Press key [Hospitality]

Use key [↑] or [↓] to select “SPILL BILL” and press [CASH] to confirm.

System prompts :< SEPARATE TABLE NO>, input the table number
[1] [CASH]

Press [Hospitality] again and select “SPILL BILL”, then press [CASH].

System prompts :< SEPARATE INDEX NO>, input the PLU index
to pay respectively. [1] [CASH]

Settle account [CASH]

INV. NO.:VBF7FT000001				
DATE:11/04/23 10:04 NO:000017				
SEPARATE TABLE: 1				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Total Amount				₹20.00
NetAmount				₹20.00
TOTAL QTY 1				₹20.00
CASH				₹20.00
SMC:65535IP:192.168.16.207				
CLERK:1				

Customers originally at No.11 table pay for the remaining items

Input the table number [1][TABLE]

Settle accounts [CASH]

INV. NO.:VBF7FT000001				
DATE:11/04/23 10:05 NO:000015				
TABLE NO: 1				
NAME	DIS	PRICE	QTY	AMOUNT
Calotte		30.00	1	30.00
Total Amount				₹30.00
NetAmount				₹30.00
TOTAL QTY 1				₹30.00
CASH				₹30.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.24 [Customer] key operation

This function is to input customer message (e.g. customer PIN) when selling commodity. (Please refer to chapter 8 ‘HOW TO INPUT CHARACTER’ for inputting characters.)

E.g.

Input the customer message

[SHIFT][Customer] [1][2][3][4][5][CASH]

[A][B][C][CASH]

Sell PLU [2] [PLU]

Settle account [CASH]

Here shows the customer message

INV. NO.:VBF7FT000001				
DATE:11/04/23 10:06 NO:000018				
CUSTOMER:12345				
VEHICLE#:ABC				
NAME	DIS	PRICE	QTY	AMOUNT
Soursop		20.00	1	20.00 B
Total Amount				₹20.00
NetAmount				₹20.00
TOTAL QTY 1				₹20.00
CASH				₹20.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.25 Hotkey Sale

Users can use hotkeys to sell the popular commodities. Refer to chapter 9.1.9 for details of hotkey setting.

Here hotkey 1 (key [V1]) set to DEPT 1, hotkey 2 (key [V2]) set to PLU4.

E.g.

Sell Dept 1 by hotkey [V1]
 Sell PLU4 by hotkey [V2]
 Settle account
 Cash [CASH]

INV. NO.:VBF7FT000001				
DATE:11/04/23 10:33 NO:000021				
NAME	DIS	PRICE	QTY	AMOUNT
DEP 001		563.00	1	563.00 A
Dress		41.00	1	41.00 D
Total Amount				₹604.00
NetAmount				₹604.00
TOTAL QTY 2				₹604.00
CASH				₹604.00
SMC:65535IP:192.168.16.207				
CLERK:1				

11.26 Hospitality

1. Press key [Hospitality], and LCD displays:

TAKEAWAY
THE NUMBER OF DINING
WAITER
COMBO
SPLIT BILL
PRINT BILL
OPEN TABLE
TABLE MERGE OUT
CANCEL TABLE

2. Use key [↑] or [↓] to select the item, and press key [CASH] to confirm.

11.26.1 Take away

This item is for sales takeaway. Refer to chapter 11.20 for details.

11.26.2 The Number Of Dining

This item is to show quantity of diner on the receipt.

1. Select 'THE NUMBER OF DINING' and press key [CASH].
2. Input the quantity of diner and press key [CASH].
3. Sell meal and then quantity of diner will show on the receipt.

11.26.3 Waiter

This item is to record the sales for each waiter. It's similar to key [Promoter] operation.

1. Select 'Waiter' and press key [CASH].
2. Input salesman/ waiter code, and press key [CASH].
3. Sell meal.

11.26.4 Combo

This item is to sell combo.

1. Select 'Combo' and press key [CASH].
2. Input Combo No., and press key [CASH].
3. Press key [CASH] to settle account.

11.26.5 Spilt Bill

This item is for clients at merged table to pay respectively. Refer to chapter 11.23 for details.

11.26.6 Print Bill

This item is to print bill on account, it's similar to key [Hold/Recall] operation.

1. Select 'Print Bill' and press key [CASH].
2. Input table No. to print its bill, and press key [CASH].

11.26.7 Open Table

This item is used to open a table to sell meal. Refer to chapter 11.21 for details.

11.26.8 Table Merge Out

This function is to combine two or more tables together to have meal in one table. Refer to chapter 11.22 for details.

11.26.9 Cancel Table

This item is used to cancel the bill of a table unpaid.

1. Select 'Cancel Table' and press key [CASH].
2. Input table No. to cancel, and press key [CASH].

11.27 Calculator Operation

The ECR has calculator function:

Press key [CAL] when the ECR is not in the transaction status, the ECR can work as a calculator.

LCD displays:

E.g.

26×3

[2][6][X][3][CASH]

Note: press key [CAL] again to exit calculation mode.

Press [CAL] Exit

78

11.28 ERP Operation

ERP operation for cash registered scale is available, such as purchase, stock checking, demand, and return and so on. Tap and hold on the key [ERP], then input the manager' number and password, and the display will show the following message:

1. SEARCH PLU STOCK
2. ADD PLU STOCK
3. DEL PLU STOCK
4. CHECK PLU STOCK

Please refer to chapter 9.1.8 for details.

11.29 Attendance

This item is to record the attendance of each clerk. Refer to chapter 12.28 for details.

12 Other Function

Tapping and holding on the key [Function] will call 'Other Function', use key [↑] or [↓] to page up or page down the display.

TOTAL (shown only when clerk logs in)
X NOPAY BILL
COM. FUNC
HOSPITALITY
DEPARTMENT SET
PLU SET
HOTKEY SET
P/O
R/A
SET HEAD MESSAGE
SET TAIL MESSAGE
TAX HEAD LINE
TAX TAIL LINE
RECEIPT HEAD DESCRIPTION KITCHEN
RECEIPT HEAD DESCRIPTION DATE AND
TIME SET
DONOT PRINT SALE REC.
TEMP TRAIN MODE
CLEAR SALES DATA
LOCK KEYBOARD
SET MENU LEVEL
PRICE INQUIRE
REDEFINE NO.
REDEFINE Z1 NO.
COM TO U DISK R/W DATA
SD/U R/W DATA
MEM.CARD
STOCK CTRL
RECORD WORK TIME
TEST NET (Ethernet model)
ZERO
TARE
Send Sale to Egame Pos

12.1 TOTAL

Note: This item is shown only when clerk logs in

This function is same as “Fix Amount Sale”, please refer to chapter 11.4 for details.

12.2 X Nopay Bill

This item is to show the unpaid bill.

12.3 COM. FUNC

Enter this function to test port communication.

12.4 Hospitality Functions

Please refer to chapter 11.26 for details.

12.5 Department Set

Please refer to chapter 9.1.2 for details.

12.6 PLU Set

Please refer to chapter 9.1.3 for details.

12.7 Hotkey Set

Please refer to chapter 9.1.9 for details.

12.8 PO

Please refer to chapter 11.12 for details.

12.9 RA

Please refer to chapter 11.11 for details.

12.10 Set Head Message

Please refer to chapter 9.6.3 for details.

12.11 Set Tail Message

Please refer to chapter 9.6.4 for details.

12.12 Tax Head/Tail Line

Please refer to chapter 10.14.2 for details.

12.13 Receipt Head Description

Please refer to chapter 9.6.5 for details.

12.14 Kitchen Receipt Head Description

This item is to set kitchen receipt head description.

12.15 Date and Time Set

Please refer to chapter 10.9 for details.

12.16 Donot Print Sale REC.

This function is to set whether to set 'PRINT SALE RECEIPT?' item 'YES' or 'NO'.

1. Use key [↑] or [↓] to choose "DONOT PRINT SALE REC.", and press key [CASH] to confirm.
2. Re-enter other function status, choose item "PRINT SALE REC." to set 'PRINT SALE RECEIPT?' to YES.

This function is the same as 'RECEIPT SET/PRINT SALE RECEIPT?' in SET mode. (Refer to chapter 9.6.24)

12.17 TEMP TRAIN MODE

This item is to switch ECR to temporary training mode.

1. Use key [↑] or [↓] to choose "TEMP TRAIN MODE.", and press key [CASH] to switch to Training mode.
2. Re-enter other function status, choose item "EXIT TEMP TRAIN MODES" to exit training mode.

12.18 Clear Sales Data

Please refer to chapter 10.6 for details.

12.19 Lock Keyboard

Use key [↑] or [↓] to choose the item 'LOCK KEYBOARD', and press [CASH] key to lock keyboard. Press [CASH] key to unlock keyboard.

12.20 Set Menu Level

Please refer to chapter 9.1.5 for details.

12.21 PRICE INQUIRE


1. Press key [FUNC], and use key [↑] or [↓] to choose "PRICE INQUIRE", then press key [CASH].
2. System prompts :< PLU CODE>, input PLU code and press key [CASH].
3. LCD displays the PLU name, and its normal price and member price.

12.22 Redefine No.

This function is to redefine the receipt number.

1. Use key [↑] or [↓] to choose the item 'REDEFINE NO', and press [CASH] key to enter.
2. Input a new start number when the LCD prompts: <INPUT NO>, and press [CASH]. Then, the receipt number will start from this new number.

Note: set the item 'SET/RECEIPT SET/PRINT RECEIPT NO ON INVOICE?' to 'NO' and 'PRINT RECEIPT NUMBER ON RECEIPT?' to 'YES'.



12.23 Redefine Z1 No.

This function is to redefine the Z1 count number.

Use key [↑] or [↓] to choose the item 'REDEFINE Z1 NO', and press [CASH] key to enter.

Input a new start number when the LCD prompts: <INPUT Z1 NO>, and press [CASH]. Then, the Z1 count number will start from this new number.

```

DATE:11/04/23 14:10
      Z DAILY REPORT
      11/04/23 14:09:39
      11/04/23 14:10:22
Z1
000011
-----
NET SALE:COUNT          1
NET SALE:AMOUNT          ₹41.00
No BUYER GSTIN SALE:COUNT  1
No BUYER GSTIN SALE:AMOUNT  ₹41.00
PROFIT:AMOUNT            ₹26.00
-----
MAN NUM:COUNT          1
-----
      TAKING
CASH:COUNT              1
CASH:AMOUNT              ₹41.00
-----
DRAWER CASH:AMOUNT      ₹41.00
-----
      CLERK REPORT
CLERK  QTY  AMOUNT
1      0001  ₹41.00
-----
      TAX REPORT
A d AMOUNT                ₹0.00
-----
A d SALES AMT             ₹0.00
NON-TAXABLE SALES AMT    ₹41.00
-----
Grand Total Amt          ₹2,161.00
SMC:65535IP:192.168.16.207
MANAGER:1

DATE:11/04/23 14:10
      GROUP REPORT
      11/04/23 14:09:39
      11/04/23 14:10:22
NAME      QTY  AMOUNT
01.GROUP 01    1    41.00

SMC:65535IP:192.168.16.207
MANAGER:1

```

Redefine the Z1 count number

12.24 COM TO U Disk R/W Data

This function is for the data transfer between ECR and U disk.

Use key [↑] or [↓] to choose the item 'U DISK R/W DATA', and press [CASH] key to enter.

System prompts: <INPUT MANAGER>, input manager number, press [CASH] key to confirm.

System prompts: <INPUT MANAGER PASW>, input manager password, press [CASH].

● **Upload Daily Report**

Connect the U disk to the cash register.

Use key [↑] or [↓] to choose the item ‘UPLOAD DAILY REPORT’, and press [CASH] key to upload daily report to your U disk.

● **Upload PLU Report**

Connect the U disk to the cash register.

Use key [↑] or [↓] to choose the item ‘UPLOAD PLU REPORT’, and press [CASH] key to upload PLU report to your U disk.

● **Upload Term Report**

Connect the U disk to the cash register.

Use key [↑] or [↓] to choose the item ‘UPLOAD TERM REPORT’, and press [CASH] key to upload term report to your U disk.

● **Upload PLU Term Report**

Connect the U disk to the cash register.

Use key [↑] or [↓] to choose the item ‘UPLOAD PLU TERM REPORT’, and press [CASH] key to upload PLU term report to your U disk.

● **Download PLU Key Report**

Connect the U disk to the cash register.

Use key [↑] or [↓] to choose the item ‘Download PLU Key Report’, and press [CASH] key to download PLU Key Report.

● **Download PLU Information**

Connect the U disk to the cash register.

Use key [↑] or [↓] to choose the item ‘DOWNLOAD PLU INFORMATION’, and press [CASH] key to download PLU information from U disk to ECR.

12.25 SD/U R/W Data

This function is for the data transfer between ECR and U disk.

1. Use key [↑] or [↓] to choose the item ‘SD/U R/W DATA’, and press [CASH] key to enter.
2. System prompts: <INPUT MANAGER>, input manager number, press [CASH] key to confirm.
3. System prompts: <INPUT MANAGER PASW>, input manager password, press [CASH] key to confirm.

This function is to read and write data in U disk. The function includes: upload daily report, upload PLU report, upload term report, upload PLU term report, download PLU key information, download PLU information, and up PLU data.

12.26 Mem. Card

This function is used for member card payment.

1. Use key [↑] or [↓] to choose “MEM. CARD”, press key [CASH].
2. Perform sales operation.
Please refer to chapter 11.16 for details.

12.27 Stock Ctrl

This function is used to control stock. If you are not authorized for the following operations, you need to input the manager's number and the password.

Please refer to chapter 9.1.8 for details.

12.28 Record Work Time

This function is used for record each clerk's working time. You can upload the "CLERK TIMECARD RECORD" report to PC to know the details.

Use key [↑] or [↓] to choose "RECORD WORK TIME", press [CASH] key to enter.

System prompts:

ON DUTY
OFF DUTY

Use key [↑] or [↓] to choose the item you want to set, press [CASH] key to enter. Then input the corresponding worker number and press [CASH].

12.29 Test Net (Ethernet model)

This function is used on the Ethernet models.

This function is to test communication. Use key [↑] or [↓] to choose "TEST NET", press key [CASH]. If the ECR makes a sound of "Bee" for a second, it means the communication is OK. If the ECR makes a sound of "Bee Bee", it means the communication is failed.

12.30 Zeroing Operation

Connect scale to the ECR, and perform zeroing operation.

12.31 Tare

Connect scale to the ECR, and perform tare operation.

12.32 Send Sale to Egame Pos

This item is to send sales record to Egame POS.

13 X/Z REPORT MODE

13.1 Introduction

This section gives instructions of printing reports. Reports are divided into two basic categories:

- X reports, which read totals without resetting.
- Z reports, which read totals and reset them to zero.

Most reports are available in both categories. Some reports, such as the 'X PROM. REPORT' and the 'X TIME REPORT' are only available as X reports.

Use key [Set Cashier] and [↑] or [↓] to shift to X mode, input the manager number and password, then press [CASH] enter X mode.

Use key [Set Cashier] and [↑] or [↓] to shift to Z mode, input the manager number and password, then press [CASH] enter Z mode.

A complete list of available reports is presented in a chart below. And an example is given for each of these reports in the pages that follow.

13.2 Report Table

Report Number	Report Name	Report Mode	Report Descriptions
1	Daily Report	X/Z	Print all sales info after last time Z daily report. It can be printed when stop working every day so as to facilitate future query.
2	Tax Term Report (for Tax Mode only)	Z	This report accumulates tax information for all Z PLU reports during the term you input.
3	PLU Report	X/Z	Print all PLU sales info after last time Z PLU report.
4	Department Report	X/Z	Print all department sales info after last time Z department report.
5	Group Report	X/Z	Read all groups' sales quantities and sum.
6	Time Report	X	Prints all sales info by hour from last time Z daily report.
7	Stock Report	X	These reports are to show the information of the stock.
8	Salesman/waiter Report	X	This report shows you the sales information of each salesman or waiter.
9	Salesman/waiter Commission Report	X/Z	This report shows you the commission of each promoter.
10	Table Report	X/Z	This report shows you the sales information of each table.
11	Nopay Bill	X	This report show you the unpaid bill list.
12	Print Set Table Name	X	Print the table's name.
13	Cancel/Void Report	X	Print date & time, item and amount of Cancel/Void operation.
14	Bill No. Report	X	Read the bill number on each receipt and its time and sales amount by a serial number interval or by a time period.
15	Bill Wise Summary Report	X/Z	Read the transaction bill details or summaries by a serial number interval or by a time period.
16	RTN Report	X/Z	This report is to show the returned commodity.

17	Cash in Drawer	X	This is a report to show the cash amount in drawer.
18	Clerk Daily Report	X	This report can show you each clerk's daily report.
19	Prn Term Rep	X	This report includes: daily term report, PLU term report, profit report.
20	Monthly Report	X/Z	This report is to show all sales information after last time Z monthly report.
21	Attendance Report	X/Z	Read clerks' attendance records.
22	Term Rep	Z	This report includes: PLU term report, term daily report

13.3 Daily Report

Daily report printed when come off work every day so as to facilitate future query.

Enter X/Z mode, use key [↑] and [↓] to select 'X DAILY REPORT' or 'Z DAILY REPORT', press key [CASH] to print.

Note: when you print Z daily report, the drawer will open automatically.

```

DATE:11/04/23 14:10
  Z DAILY REPORT
11/04/23 14:09:39
11/04/23 14:10:22
Z1                000011
-----
NET SALE:COUNT      1
NET SALE:AMOUNT      ₹41.00
No BUYER GSTIN SALE:COUNT  1
No BUYER GSTIN SALE:AMOUNT
                        ₹41.00
PROFIT:AMOUNT        ₹26.00
-----
MAN NUM:COUNT      1
-----
                    TAKING
CASH:COUNT          1
CASH:AMOUNT          ₹41.00
DRAWER CASH:AMOUNT  ₹41.00
-----
                    CLERK REPORT
CLERK  QTY  AMOUNT
1      0001  ₹41.00
-----
                    TAX REPORT
A d AMOUNT            ₹0.00
-----
A d SALES AMT        ₹0.00
NON-TAXABLE SALES AMT  ₹41.00
-----
Grand Total Amt      ₹2,161.00
SMC:65535IP:192.168.16.207
MANAGER:1

DATE:11/04/23 14:10

                    GROUP REPORT
11/04/23 14:09:39
11/04/23 14:10:22
NAME      QTY  AMOUNT
01.GROUP 01      1    41.00

SMC:65535IP:192.168.16.207
MANAGER:1

```


13.4 Tax Term Report

In Z mode, use key [↑] or [↓] to choose item 'TAX TERM REPORT', and press key [CASH].

BY DATE
BY Z1 Count

If you choose 'BY DATE', press [CASH], the system prompts: <DATE TERM (DDMMYYDDMMYY)>, DD is day, MM is month, YY is year, input the start date and end date.

If you choose 'BY Z1 Count', press [CASH], the system prompts: <INPUT Z1 Count (SSSSEEEE)>, SSSS is the start Z1 count number, EEEE is the end Z1 count number.

By date:

By Z1 count:

```

DATE:11/04/23 16:41
TAX TERM REPORT
10/04/2023 --- 11/04/2023
-----
Z1 0001      11/04/2023
AMOUNT                ₹0.00
TAX                   ₹0.00
-----
Z1 0002      11/04/2023
AMOUNT                ₹20.00
TAX                   ₹0.00
-----
TOTAL AMOUNT          ₹20.00
TOTAL TAX              ₹0.00
SMC:65535IP:192.168.16.207
MANAGER:1
    
```

```

DATE:11/04/23 16:42
TAX TERM REPORT
0001 --- 0005
-----
Z1 0001      11/04/2023
AMOUNT                ₹0.00
TAX                   ₹0.00
-----
Z1 0002      11/04/2023
AMOUNT                ₹20.00
TAX                   ₹0.00
-----
TOTAL AMOUNT          ₹20.00
TOTAL TAX              ₹0.00
SMC:65535IP:192.168.16.207
MANAGER:1
    
```

13.5 PLU Report

Enter X/Z mode, use key [↑] and [↓] to select 'X PLU REPORT' or 'Z PLU REPORT', press key [CASH] to enter.

System prompts: <Input DEP num to print (0 PRINT ALL)>, input the department number, and then press [CASH] key to print PLU report. If you want to print all PLU information, input 0 here.

```

DATE:11/04/23 10:58
X PLU REPORT
DEP 001
11/04/23 10:39:24
11/04/23 10:58:01

SL  ItemName  QTY  AMOUNT
1   Calotte   2     60.00
2   Dress     1     41.00
3   Jeans     2     30.00
-----
TOTAL:  5     ₹131.00

SMC:65535IP:192.168.16.207
MANAGER:1
    
```

13.6 Department Report

Department report prints all department sales info after last time Z department report.

Enter X/Z mode, use key [↑] and [↓] to select 'DEPARTMENT REPORT' or 'Z DEPARTMENT REPROT'. Press key [CASH] to print department report.



DATE:11/04/23 10:58

DEPARTMENT REPORT

11/04/23 10:39:24
11/04/23 10:58:15

NAME	PRIVATE DIS	QTY	AMOUNT
DEP 001	0.00	6	694.00
DEP 002	0.00	5	98.00
	-2.00		

SMC:65535IP:192.168.16.207
MANAGER:1

13.7 Group report

Group report prints all groups' sales quantities and sum.

Enter X/Z mode, use key [↑] and [↓] to select "X GROUP REPORT" or 'Z GROUP REPORT'.. Press key [CASH] to print group report.



DATE:11/04/23 10:58

GROUP REPORT

11/04/23 10:52:23
11/04/23 10:58:23

NAME	QTY	AMOUNT
01.GROUP 01	6	694.00
02.GROUP 02	4	78.00

SMC:65535IP:192.168.16.207
MANAGER:1

13.8 Time Report

This prints all sales info by an hour after last time Z daily report.

In X mode, use key [↑] or [↓] to choose 'X TIME REPORT', press [CASH] key to print

Time ← DATE:11/04/23 10:58

TIME REPORT

11/04/23 10:39:24
11/04/23 10:58:31

TIME	RATE	QTY	AMOUNT
10--11	0.00%	7	₹792.00
TOTAL			₹792.00

SMC:65535IP:192.168.16.207
MANAGER:1

How many net sales have been generated during this period. ←

13.9 Stock Report

These are three reports are to show the information of the stock.

In X mode, use key [↑] or [↓] to choose 'STOCK REPORT', press [CASH] key to enter.

13.9.1 STOCK WARNING REPORT

1. Use key [↑] or [↓] to choose 'STOCK WARNING REPORT', press [CASH] key to enter.
2. System prompts: <INPUT WARNING STOCK>, input warning stock, press [CASH] key to print. (E.g. if you set the warning stock as 90, then the 'STOCK WARNING REPORT' will show you the PLU with stock under 90.)

DATE:11/04/23 15:46

WARNING STOCK REPORT

NAME DEP	STOCK AMOUNT
Turnip 3	0 ₹0.00
Plum 1	0 ₹0.00
PLU279 1	0 ₹0.00
Apple 3	0 ₹0.00
TOTAL:	₹0.00

SMC:65535IP:192.168.16.207
MANAGER:1

13.9.2 PLU STOCK WARNING REPORT

This item is to print PLU Stock warning report.

Use key [↑] or [↓] to choose 'PLU STOCK WARNING REPORT', press [CASH] key to print.

DATE:20/02/23 15:10

WARNING STOCK REPORT

NAME DEP	STOCK AMOUNT
Apple 3	0 ₹0.00
=====	
TOTAL:	₹0.00

SMC:65535IP:192.168.16.207
MANAGER:1

13.9.3 X STOCK REPORT

1. Use key [↑] or [↓] to choose 'X STOCK REPORT', press [CASH] key to enter.
2. System prompts: <INPUT DEPARTMENT>, input the department number, press [CASH] key to print stock report under this department.

DATE:11/04/23 15:49

X STOCK REPORT


NAME DEP	STOCK AMOUNT
Soursop 2 0.00%	9947 ₹169,099.00
=====	
TOTAL:	₹169,099.00

SMC:65535IP:192.168.16.207
MANAGER:1

13.10 X Salesman/Waiter Report

This report shows you the sales information of each salesman or waiter.

In X mode, use key [↑] or [↓] to choose 'X SALESMAN/WAITER REPORT', press [CASH] key to print.




13.11 Salesman/Waiter Commission Report

This report shows you the commission information of each promoter.

In X mode or Z mode, use key [↑] or [↓] to choose 'X SALESMAN/WAITER COMMISSION REPORT' or 'Z SALESMAN/WAITER COMMISSION REPORT', press [CASH] key to print.


Note: you must set the commission rate before (refer to chapter 9.1.2 for details), and set the item 'CLERK OPERATION/ SALESMAN/WAITER WORK ON COMMISSION?' to 'YES' in SET mode.



13.12 Table Report

This report shows you the sales information of each table.


In X/Z mode, use key [↑] or [↓] to choose 'X TABLE REPORT' or 'Z TABLE REPORT', and press [CASH] key to print.



13.13 Nopay Bill

This report show you the unpaid bill list.

In X mode, use key [↑] or [↓] to choose 'X NOPAY BILL', and press [CASH] key to print.



13.14 Print Set Table Name

This item is to print tables' name.

In X mode, use key [↑] or [↓] to choose 'Print Set Table Name', and press [CASH] key to print.

13.15 X Cancel/Void Report

This report is to read all canceled or void transaction information.

In X mode, use key [↑] or [↓] to choose ‘X CANCEL/VOID. REPORT’, press [CASH] key to print.

DATE:11/04/23 15:02	
Prn Rtn VOID MODE 0	
23/04/11 14:13 0	
Soursop X 1	₹20.00
23/04/11 15:02 0	
Soursop X 1	₹20.00
SUBTOTAL X 2	₹40.00
TOTAL X 2	₹40.00
SMC:65535IP:192.168.16.207 MANAGER:1	

13.16 X Bill NO. Report

This report can show you the sales sum and date/time in each receipt.

Enter X mode and use [↑] or [↓] to choose “X BILL NO. REPORT”, press [CASH].

Use [↑] or [↓] to page up and page down the display:

<p>X BL_NO. REPORT BY BL_NO. X BL_NO. REPORT BY TIME</p>
--

You can select < X BL_NO.REPORT BY BL_NO.> then input the beginning bill no. and the end bill no. as the LCD prompts, and press [CASH] to print the X bill no. report.

You can also select <X BL_NO..REPORT BY TIME> to input the <Start Bill No. DATE (DDMMYYYY)> and (Start Bill NO. TIME (HHMM)>, then input the <End Bill No. DATE (DDMMYYYY)> and (End Bill NO. TIME (HHMM)> as the LCD prompts, and finally press [CASH].

By Serial No.:

DATE:11/04/23 15:03			
SERIAL NO. REPORT			
BL_NO	DATE	TIME	AMOUNT
00000005	07/04/23	15:04	₹1.00
00000004	07/04/23	15:03	
			₹563.00
00000003	07/04/23	14:36	₹2.00
00000002	07/04/23	14:33	₹1.00
00000001	07/04/23	14:32	₹1.00
TOTAL			₹568.00
SMC:65535IP:192.168.16.207 MANAGER:1			

By Time:

DATE:11/04/23 15:06			
SERIAL NO. REPORT			
BL_NO	DATE	TIME	AMOUNT
00000127	11/04/23	15:02	₹30.00
00000126	11/04/23	14:55	₹20.00
00000125	11/04/23	14:55	₹20.00
00000124	11/04/23	14:53	₹20.00
00000123	11/04/23	14:53	₹20.00
00000122	11/04/23	14:50	₹30.00
00000121	11/04/23	14:50	₹20.00
00000120	11/04/23	14:47	
			₹1,000.00
00000119	11/04/23	14:47	
			₹500.00
TOTAL			₹1,660.00
SMC:65535IP:192.168.16.207 MANAGER:1			

13.17 Bill Wise Summary Report

This report shows the transaction bill wise detailed report and summary report.


In X mode/Z mode, use key [↑] or [↓] to choose ‘BILL WISE SUMMARY REPORT’, press [CASH].

Use [↑] or [↓] to page up and page down the display:



use key [↑] or [↓] to choose “DETAILED” or “SUMMARY”, press [CASH].

LCD displays:



use key [↑] or [↓] to choose “BL_NO. TO BL_NO.” or “DATE TO DATE”, system will prompt to input the start and end serial number, or the start and end date and time, input date or serial number according to your choice, and then press [CASH] to print report.

Bill wise detailed report:

DATE:11/04/23 15:07

BILL WISE DETAILED REPORT

BL_NO	TBL	WTR	CV	AMOUNT
TAX	DIS			TOTAL MOD
07/04/23				
00000001	0	0	1	1.00
0.00	0.00			1.00CASH
00000002	0	0	1	1.00
0.00	0.00			1.00CASH
00000003	0	0	1	2.00
0.00	0.00			2.00CASH
00000004	0	0	1	563.00
0.00	0.00			563.00CASH
TAX	₹0.00	DIS		₹0.00
TOTAL				₹567.00

SMC:65535IP:192.168.16.207
MANAGER:1

Bill wise summary report:

DATE:11/04/23 15:07

BILL WISE SUMMARY REPORT

TAX	₹0.00	DIS	₹0.00
TOTAL			₹567.00

SMC:65535IP:192.168.16.207
MANAGER:1

13.18 RTN Report

This report is to show the returned commodity.

In X or Z mode, use key [↑] or [↓] to choose 'X RTN REPORT' or 'Z RTN REPORT', press [CASH] key to print.

X RTN REPORT		
11/04/23 10:39:24		
11/04/23 16:29:11		
NAME	QTY	AMOUNT
Soursop	1	20.00
TOTAL:	1	₹20.00
SMC:65535IP:192.168.16.207		
MANAGER:1		

13.19 Cash In Drawer

This is a report to show the record of RA/PO operation and the cash amount in drawer.

In X mode, use key [↑] or [↓] to choose 'Cash In Drawer', press [CASH] key to print.

DATE:11/04/23 16:29	
CASH IN DRAWER REPORT	
R/A:AMOUNT	₹5.00
DRAWER CASH:AMOUNT	₹4,488.95
SMC:65535IP:192.168.16.207	
MANAGER:1	

13.20 Clerk Daily Report

This is a report to show the daily sales information of each clerk.

In X mode, use key [↑] or [↓] to choose 'X CLERK DAILY REPORT', press [CASH].

The system prompts: <Input clerk>, input the clerk code, and press [CASH] key to confirm.

The system prompts: <Input drawer amount>, input the drawer amount, and press [CASH] key to confirm, or press [CASH] key directly to print this report.

```

DATE:11/04/23 16:29
11/04/23 14:10:25
11/04/23 16:29:40
CLERK: 1 DAILY REPORT
NET SALE:COUNT 18
NET SALE:AMOUNT ₹4,422.95
No BUYER GSTIN SALE:COUNT 17
No BUYER GSTIN SALE:AMOUNT
₹4,442.95
- -:COUNT 1
- -:AMOUNT -₹2.05
E/C:COUNT 1
E/C:AMOUNT -₹30.00
VOID:COUNT 2
VOID:AMOUNT -₹40.00
RTN:COUNT 1
RTN:AMOUNT -₹20.00
MAN NUM:COUNT 17
R/A:COUNT 1
R/A:AMOUNT ₹5.00
TAKING
CASH:COUNT 18
CASH:AMOUNT ₹4,422.95
DRAWER CASH:AMOUNT ₹4,427.95
Input drawer amount:AMOUNT
₹4,488.95
DRAWER AMT MARGIN:AMOUNT
₹61.00
SMC:65535IP:192.168.16.207
MANAGER:1

```

13.21 PRN Term Report

In X mode, use key [↑] or [↓] to select the item 'Prn Term Report', press key [CASH] to enter. Use [↑] or [↓] to page up and page down the display:

```

X DAILY TERM REPORT
X PLU TERM REPORT
X PLU RETURN TREM REPORT
X PROFIT REPORT

```

● **X Daily Term Report**

Accumulate sales information for all Z daily reports from last time Z term report.

Use key [↑] or [↓] to select the item 'X DAILY TERM REPORT', press key [CASH] to print daily term report.

```

DATE:11/04/23 16:31

  X TERM REPORT

00/00/00 00:00:00
11/04/23 16:31:33

NET SALE:COUNT          115
NET SALE:AMOUNT          ₹11,195.15
No BUYER GSTIN SALE:COUNT 112
No BUYER GSTIN SALE:AMOUNT
                          ₹11,188.15
BUYER GSTIN SALE:COUNT    1
BUYER GSTIN SALE:AMOUNT    ₹47.00
SAVING FOR MEM.:AMOUNT     ₹3.00
-----
-%:COUNT                 4
-%:AMOUNT                 -₹11.70
E/C:COUNT                 3
E/C:AMOUNT                 -₹76.00
VOID:COUNT                 3
VOID:AMOUNT                 -₹64.50
ALL VOID:COUNT            2
ALL VOID:AMOUNT            -₹121.00
-----
R/A:COUNT                 3
R/A:AMOUNT                 ₹401.00
P/O:COUNT                 2
P/O:AMOUNT                 -₹500.00
-----
MAN NUM:COUNT            113
TAKEAWAY:COUNT           1
TAKEAWAY:AMOUNT           ₹20.00
-----
                        TAKING
CASH:COUNT                111
CASH:AMOUNT                ₹11,055.15
CREDIT:COUNT               2
CREDIT:AMOUNT               ₹40.00
PAYMENT2:COUNT            2
PAYMENT2:AMOUNT            ₹100.00
-----
                        TAX REPORT
A d AMOUNT                  ₹0.00
-----
A d SALES AMT                ₹0.00
NON-TAXABLE SALES AMT
                          ₹7,587.75
-----

SMC:65535IP:192.168.16.207
MANAGER:1
  
```

● **X PLU TERM REPORT**

This report is to read PLU sales information for all PLU reports after the previous PLU term report.

Use key [↑] or [↓] to select the item ‘X PLU TERM REPORT’, press key [CASH] to print PLU term report.

DATE:11/04/23 16:31		
X PLU TERM REPORT		
00/00/00 00:00:00		
11/04/23 16:31:57		
NAME	QTY	AMOUNT
Lemon	51	₹330.00
Soursop	42	₹720.00
Calotte	25	₹653.50
Dress	14	₹530.90
Jeans	4	₹60.00
Vest	1	₹18.00
PLU 9	7	₹300.00
PLU10	7	₹138.00
Mush	1	₹9.90
TOTAL:	152	₹2,760.30
SMC:65535IP:192.168.16.207		
MANAGER:1		

● **X PLU RETURN TREM REPORT**

This report is to read return PLU information.

Use key [↑] or [↓] to select the item ‘X PLU RETURN TERM REPORT’, press key [CASH] to print PLU return term report.

Note:

1. Set the item ‘OPTION OF CLEAR REPORT/ CLEAR PLU RTN REP WHEN CLEAR DAILY REP?’ to ‘YES’ in SET mode.
2. Clear Z Daily Report before printing X PLU Return Term Report.

DATE:11/04/23 16:32		
X RTN TERM REPORT		
11/04/23 10:39:24		
11/04/23 16:32:08		
NAME	QTY	AMOUNT
Soursop	2	40.00
TOTAL:	2	₹40.00
SMC:65535IP:192.168.16.207		
MANAGER:1		

● X Profit Report

This report is to read the sales profits in a time period..

In X mode, use key [↑] or [↓] to choose the item 'X PROFIT REPORT', and press key [CASH] to enter.

Input START DATE and END DATE, the format is DDMMYYYY (DD indicates day, MM indicates month, and YYYY indicates year).

Z1	DATE	AMOUNT	PROF
000001	11/04/23	₹0.00	₹0.00
000002	11/04/23	₹20.00	₹3.00

TOTAL		₹0.00	₹3.00

DATE:11/04/23 16:32
PROFIT REPORT
11/04/23 ---12/04/23
SMC:65535IP:192.168.16.207
MANAGER:1

13.22 Z Term Report

In Z mode, use key [↑] or [↓] to select the item 'Z Term Report', press key [CASH] to enter.

Use [↑] or [↓] to page up and page down the display:

Z PLU TERM REPORT
Z PLU RETURN TREM REPORT
Z TERM DAILY REPOR

Use [↑] or [↓] to select one item, and press [CASH] key to print.

13.23 Monthly Report

In X/Z mode, use key [↑] or [↓] to choose the item 'X MONTHLY REPORT' or 'Z MONTHLY REPORT', and press key [CASH] to print.

```

DATE:11/04/23 16:32
X MONTHLY REPORT
00/00/00 00:00:00
11/04/23 16:32:56

NET SALE:COUNT          115
NET SALE:AMOUNT          ₹11,195.15
No BUYER GSTIN SALE:COUNT 112
No BUYER GSTIN SALE:AMOUNT
                          ₹11,188.15
BUYER GSTIN SALE:COUNT   1
BUYER GSTIN SALE:AMOUNT   ₹47.00
SAVING FOR MEM.:AMOUNT    ₹3.00
-----
-%:COUNT                 4
-%:AMOUNT                 -₹11.70
E/C:COUNT                 3
E/C:AMOUNT                -₹76.00
VOID:COUNT                 3
VOID:AMOUNT               -₹64.50
ALL VOID:COUNT            2
ALL VOID:AMOUNT           -₹121.00
-----
R/A:COUNT                 3
R/A:AMOUNT                 ₹401.00
P/O:COUNT                 2
P/O:AMOUNT                 -₹500.00
-----
MAN NUM:COUNT            113
TAKEAWAY:COUNT           1
TAKEAWAY:AMOUNT           ₹20.00
-----
                        TAKING
CASH:COUNT                111
CASH:AMOUNT                ₹11,055.15
CREDIT:COUNT               2
CREDIT:AMOUNT              ₹40.00
PAYMENT2:COUNT            2
PAYMENT2:AMOUNT            ₹100.00
-----
                        TAX REPORT
A d AMOUNT                 ₹0.00
-----
A d SALES AMT              ₹0.00
NON-TAXABLE SALES AMT
                          ₹7,587.75
-----

SMC:65535IP:192.168.16.207
MANAGER:1

```

13.24 Attendance report

This report shows all clerks' attendance records during the time period that you input.

In X/Z mode, use key [↑] or [↓] to choose the item 'ATTENDANCE REPORT' or 'Z ATTENDANCE REPORT', and press key [CASH] to enter.

Input START DATE and END DATE, the format is DDMMYYYY (DD indicates day, MM indicates month, and YYYY indicates year). And then press [CASH] key to print.

```
DATE:11/04/23 16:39
ATTENDANCE REPORT
10/04/23 ---11/04/23
1 ON DUTY 11/04/23 16:37
3 ON DUTY 11/04/23 16:38
SMC:65535IP:192.168.16.207
MANAGER:1
```

Clerk code ←

14 ERROR INFORMATION

Format of familiar error information is ERR X

Error code and description

Error number	Description
1	Invalid key input
2	Clerk doesn't login
3	Invalid digit length
4	[.] input error
5	Invalid clerk code
6	QTY/WT input error
7	[E/C] input error
8	[-] input error
9	[+%] input error
10	[-%] input error
11	[Void] input error
12	Dept. data error
13	[PRICE] input error
14	[FC] input error
15	Scale communication error
16	[CASH] input error
17	[CREDIT] input error
18	[CHECK] input error
19	Please print Z daily report
20	Password input error
21	Please input amount before payment
22	Time setting error
23	PLU barcode setting error
24	Barcode check sum error
25	Print speed setting error
26	Date setting error
27	Flash writing error
28	Daily report printing error
29	Sold items over 100 in 1 receipt
30	[SAVE] input error
31	Saved records full (MAX.: 5)
32	[RECALL] input error
33	No Hard reset Error
34	[CARD] input error
35	Inexistent PLU
36	PLU QTY full
37	Flash not found
38	Flash writing error
39	Flash full
40	PLU name error
41	Password input error

42	Z daily report error
43	PLU QTY near full
44	Data input error
45	Clerk exists
46	Clerk full
47	Scale weight error
48	Unfinalized sales
49	Payment mode error
50	Cash in drawer over
51	User password error
52	Cash in drawer short
53	R/A amount over
54	P/O amount over
55	Inexistent PLU
56	Price error
57	Item amount error
58	Daily total error
59	PLU Report error
60	Fiscal code length error
61	Fiscal code & num error
62	Fiscal number error
63	Tax format error
64	Tax ID error
65	Tax number error
66	Write Eprom error
67	This Plu no sale
68	Inexistent tax rate
69	Department No. error
70	Tax area full
71	Fiscal code error
72	Download setting error
73	Full fiscal memory
74	Fiscal memory writing error (in Z report)
75	Data in Fiscal memory error
76	Full PLU data
77	PLU can't be returned
78	Batch NO. not found
79	Batch NO. input error
80	No paper roll
81	No receipt paper
82	No journal paper
83	Invalid Member Card No.
84	Sales forbidden
85	Data in Nand Flash ERROR
86	Dept. tax rate error
87	PLU/Stock data under processing
88	Table No. error or table isn't opened
89	Sales No. error or sales isn't inputted

90 Split payment error
 91 Receipt No. not found
 92 Z1 report No. not found
 93 Buffer for voided items full
 94 [Meal] input error
 95 Payment mode error
 96 [+] input error
 97 LOOP check error
 98 Communication time out
 99 CARD isn't empty
 100 Invalid card No.
 101 Net communication error
 102 Please download the sales data first
 103 IC card password input error
 104 Net Busy, MEM. Limit sale data not downloaded
 105 PLU Limit Sale QTY break bound
 106 PLU Limit Sale Max 80 recode in one receipt
 107 PLU Limit Sale PC Confirm Error
 108 Rtn Report Overage
 109 Manager NO. Error
 110 Manager have not this purview
 111 Net Busy, MEM. have to sale by Normal MEM.
 112 IP Address Confict
 113 Have subtotal dis in receipt
 114 Have Table no pay, Can't enter this function
 115 Warning!! Please upload sale data
 116 Press REMARK key error
 117 Input Qty Error
 118 This PLU have relate discount, Can't be VOIDED
 119 Clerk login area full, please upload
 120 NO SALE ERROR
 121 EXT ECR NO ERROR
 122 NO FIND CARD NO DATA TO COPY
 123 No Login
 124 Remain No Enough
 125 M1 card type error
 126 Can't PAY by this card
 127 This M1 card can't RETURN here
 128 This M1 card can't ADD AMOUNT here
 129 This M1 card can't ISSUE here
 130 This M1 card can't COPY here
 131 Combin data error
 132 Remain Amt Overlary
 133 COM init error, please power off/on ECR
 134 Class NO. error
 135 Net busy, Can't download MEM. Cumulate
 136 This plu can't trade
 137 Cumulate no enough

138 MEM. cumulate trade confirm error
 139 Password in ECR error
 140 Rec. limit sale qty error
 141 QTY ERROR,TOTAL AMOUNT DISCOUNT
 142 Max limit pay amt error
 143 Max limit add amt error
 144 Negative stock no allow sell
 145 Only can input T barcode
 146 PLS INPUT M1 USER PSW
 147 Max limit add amt error
 148 This M1 card can`t CHANGE PSW here
 149 Total Discount Can't Cancel
 150 System time error,Please contact surfaceman
 151 There are some SAVED rec,no allow logout
 152 There are some SAVED rec,no allow Z REP
 153 Disk full or allocation exceeded
 154 Connection time out
 155 Communication protocol Error
 156 UnKnow FAT
 157 USB disk unreachable
 158 Access violation
 159 file compare error
 160 File not found
 161 File already exists
 162 Filename Error
 163 Communication End
 164 SET TAX PROPRITY ERROR
 165 NEVER ADJUST TIME
 166 ECR TIME OVERFLOW WARNING
 167 VALID BARCODE LEN TOO LONG
 168 Low battery or short-circuit for RAM
 169 This function used in TABLE ver
 170 Card valid date overwrite
 171 [TOTAL PRICE] input error
 172 M1 Card already stop
 173 M1 Card already start
 174 WEIGHT IS NEGATIVE,CAN'T TARE
 175 WEIGHT IS ZERO,CAN'T SALE
 176 PLEASE UPLOAD TRANSACTION FIRST
 177 NO CASH PAYMENT
 178 NO FINDTHE DATA
 179 PLEASE CHANGE TO TAX MODE FIRST
 180 PLEASE SET "UPLOAD TRANSACTION TO PC?" FIRST
 181 PLEASE SET "PRINT RECEIPT AFTER CHECK OUT?" FIRST
 182 PLEASE SET "USE DND SALE?" FIRST
 183 PLEASE SET "SUBTOTAL DISCOUNT?" FIRST
 184 PLEASE SET "MIX. AND MATCH DISCOUNT?" FIRST
 185 PLEASE SET "PLU MANUAL DISCOUNT?" FIRST

186 PLEASE SET "KITCHEN PRINT RECEIPT AFTER CHECK OUT?" FIRST
187 PLEASE SET "REPRINT RECEIPT BY [CASH] KEY?" FIRST
188 PLEASE SET "USE VOUCHER/LIMITED PAYMENT?" FIRST
189 NO ALLOW MANUAL CHANGE PRICE
190 PLEASE SET "PRINT NON-SALE RECEIPT?" FIRST
191 OVER CREDIT AMOUNT
192 Short of memory, please upload layby transaction asap.
193 Please print Z monthly report
194 UPS communication error
195 PLEASE SET "SAVE MEMBER POINTS IN ECR?" FIRST
196 Unit error
197 Weight Not Change
198 OP box Connection time out
199 PLEASE SET "PRINT SALE RECEIPT?"
200 Rtn Term Report Overage
201 Non paper of journal and receipt
202 Compensation time setting error
203 Please log out

15 APPENDIX

➤ Bar Code Type Table

This ECR support 13 digits EN-13 code. When the first digit is 2, this bar code is considered as inner code. Generally speaking, the last digit (S) used as check code. This ECR can select 10 inner barcode, which start with 2X (20~29), from the 65 types of code. Following is inner bar code, where C stand for Code, W stand for Weight or Quantity, P stand for Price. User can set bar code type in SET mode.

Barcode Type	Start Code	Code	Weight or Qty.	Check Sum
0	2X	C	WWWWWWWWW	S
1	2X	C	WWWWWWW.W	S
2	2X	C	WWWWWWW.WW	S
3	2X	C	WWWWW.WWW	S
4	2X	CC	WWWWWWW	S
5	2X	CC	WWWWWWW.W	S
6	2X	CC	WWWWW.WW	S
7	2X	CC	WWWWW.WWW	S
8	2X	CCC	WWWWWWW	S
9	2X	CCC	WWWWW.W	S
10	2X	CCC	WWWWW.WW	S
11	2X	CCC	WWW.WWW	S
12	2X	CCCC	WWWWW	S
13	2X	CCCC	WWWWW.W	S
14	2X	CCCC	WWW.WW	S
15	2X	CCCC	WWW.WWW	S
16	2X	CCCCC	WWWWW	S
17	2X	CCCCC	WWW.W	S
18	2X	CCCCC	WWW.WW	S
19	2X	CCCCC	WW.WWW	S
20	2X	CCCCCC	WWWW	S
21	2X	CCCCCC	WWW.W	S
22	2X	CCCCCC	WW.WW	S
23	2X	CCCCCC	W.WWW	S
24	2X	CCCCCC	WWW	S
25	2X	CCCCCC	WW.W	S
26	2X	CCCCCC	W.WW	S
27	2X	CCCCCC	0.WWW	S
28	2X	CCCCCC	WW	S
29	2X	CCCCCC	W.W	S
30	2X	CCCCCC	0.WW	S
31	2X	CCCCCC	0.0WW	S
32	2X	CCCCCC	W	S
33	2X	CCCCCC	0.W	S
34	2X	CCCCCC	0.0W	S
35	2X	CCCCCC	0.00W	S
36	2X	CCCCCC		S

Barcode Type	Start Code	Code	Weight or Qty.	Check Sum
37	2X	C	PPPPPPP.PP	S
38	2X	CC	PPPPPP.PP	S
39	2X	CCC	PPPPP.PP	S
40	2X	CCCC	PPPP.PP	S
41	2X	CCCCC	PPP.PP	S
42	2X	CCCCCC	PP.PP	S
43	2X	CCCCCC	P.PP	S
44	2X	CCCCCC	0.PP	S
45	2X	CCCCCC	0.0P	S
46		CCCCCCCCCCCC		
47	2X	C	PPPPPPPP	S
48	2X	CC	PPPPPP	S
49	2X	CCC	PPPPPP	S
50	2X	CCCC	PPPP	S
51	2X	CCCC	PPPP	S
52	2X	CCCC	PPP	S
53	2X	CCCC	PPP	S
54	2X	CCCC	PP	S
55	2X	CCCC	P	S
56	2X	C	PPPPPP.P	S
57	2X	CC	PPPPPP.P	S
58	2X	CCC	PPPPP.P	S
59	2X	CCCC	PPPP.P	S
60	2X	CCCC	PPPP.P	S
61	2X	CCCC	PPP.P	S
62	2X	CCCC	PP.P	S
63	2X	CCCC	0P.P	S
64	2X	CCCC	00.P	S

